






# Assembly Instructions

**Caution : You must read this before you proceed**




## ACCENT CHAIR





### Parts List

Label	Picture	Description	QTY
A		Chair Back	1
B		Chair Seat	1
C		Right Front Leg	1
D		Left Front Leg	1




### Hardware

Label	Picture	Description	QTY
①		Bolt (M8*80)	5
②		Bolt (M8*65)	5
③		Washer	9

④		Spring Washer	9
⑤		Allen Key	1

## Assembly Preparation

Before  
Beginning  
Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-

## Assembly Steps


### Overview




This Accent Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Accent Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

### Step 1.1

Seat Base Cover





B



## Step 1


Place the Chair Seat(B) Face down on a soft surface to avoid any scratches or damages to the product.  
Carefully peel away the Seat Base Cover from the edge, take out the legs and hardware from the Bottom of the Chair Seat (B).

### Step 1.2



Put the Chair Back(A) onto a flat, clean, non-marring table.  
Align the mounting positions of the Chair Back(A) and Chair Seat (B).  
Use your left hand to push the seat floorwards, depicted by Arrow 1.  
This action helps to ensure the Chair Seat(B) is pressed towards to the Chair Back(A) with no gap between them.  
Using Bolts(①), Spring Washers(④) and Washers(③) with Allen Key(⑤) as shown above.  
**Do not fully tighten Bolts.**


## Step 2



Place the chair onto the side of a table as seen in picture 1.  
Position Left Front Leg(D) into Chair Seat(B) and attach using Bolts(②), Spring Washers(④) and Washers(③) with Allen Key(⑤).  
Repeat same step to attach Right Front Leg (C) to Chair Seat(B).  
Do not fully tighten Bolts.  
**WARNING!! DO NOT POSITION THE FRONT LEG AS SHOWN IN PICTURE 2.**


**THIS PICTURE SHOWS THE CHAIR BACK STAYS AGAINST THE GROUND and THE FRONT LEGS HORIZONTAL IN MIDAIR.**  
**WARNING!! DO NOT OVER TIGHTEN. OVER TIGHTENING COULD LEAD TO DAMAGE OF THE PRODUCT.**  
**TIGHTEN ONLY UNTIL SECURE AND STABLE.**

### Step 3



Place the Accent Chair on a Level Surface to see if it wobbles.  
 If it wobbles, lift the accent chair some 30cm to 50cm high from the ground.  
 Keep your feet and toes well away from the drop zone.  
 Drop the Chair freely and vertically with all four legs, hitting the ground, at the same time.  
 This Drop Test will help to ensure that all Bolts, and gaps reach full alignment status.  
 Test again for evenness on a Level Surface.  
 If no wobbles are found, proceed to tighten all the Bolts.  
 Note: When tightening the Bolts, tighten sequentially. Do not tighten any Bolt or fully and then move towards the next one. This could cause the frame to warp.  
 If there are still wobbles, loosen the Bolts and execute this same drop test.  
 Note: If the accent chair is not stable, it could lead to damage to the product.

### Step 4



Place the Seat Base Cover back as shown in picture.  
 Smooth the Magic Tape down with your hand on all four sides at the edge of the seat.  
 Make sure all parts are connected and securely locked into position.  
 Then stang the Accent Chair up.  
 Your Accent Chair is ready for use.  
 This Accent Chair can only be used on a flat, level surface.

## Care & Maintenance



Do not put hot items directly on furniture surface



Do not clean furniture with harsh cleansers or polish.



Do not place furniture under direct sunlight.



Do not place furniture near heating or cooling vents.



Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside . For indoor use only .



Not for commercial use. For residential use only .



Stains may be removed with mild soap solution and damp cloth.



Children should not climb or jump on the furniture.



Dust and pick-up spills using a clean, non-colored, lint-free cloth .