


27
28
24
22
21
27
25
23
15
20
19
18
11
16
26
13
31
12
25
14
5
21
32
4
1
3
6
17
2
7
8
9
10
17
17
30
29
17
30
29

CODR	DESRIPTION	QTY
1	Center Back Stand Strip	1
2	Left Center Stand Strip	1
3	Center Stand Strip	1
4	Right Center Stand Strip	1
5	Intermediate Bottom Plate	1
6	Center Front Stand Strip	1
7	Left Bottom Plate	1
8	Left Back Stand Strip	1
9	Left Side Stand Strip	1
10	Left Front Stand Strip	1
11	Right Bottom Plate	1
12	Right Back Stand Strip	1
13	Right Side Stand Strip	1
14	Right Front Stand Strip	1
15	Right Intermediate Plate	1
16	Left Intermediate Side Plate	1
17	Side Plate Front Retainer Strip	4
18	Intermediate Layer	1
19	Smaller Intermediate Front Retainer Strip	1
20	Smaller Intermediate Side	1
21	Left & Right Side Plate	2

CODR	DESRIPTION	QTY
22	Intermediate Top Plate	1
23	Left Top Plate	1
24	Right Top Plate	1
25	Left & Right Adjustable Board	2
26	Intermediate Adjustable Board	1
27	Side Panel	2
28	Center Panel	1
29	Left Door Panel	2
30	Right Door Panel	2
31	Fireplaces Back Strip	1
32	Fireplaces Under Strip	1

PACKAGE CONTENT

A Ø15  67X+4X	B  67X+4X	C Ø8x30mm 52X+4X	D 4X
E Φ5/32"×25mm 8X	F  4X	G  4X	H 8X
I M6×50mm  4X	J ST3.5*16mm  38X+3X	K ST3.5*12mm 32X+3X	L  4X+4X
M  8X	N ST3.5*12mm 32X+3X	O Ø1/4"×12mm 28X+2X	P ST3.9*30mm  3X
Q  12X+1X	R  40X+4X	S  2X+4X	T  2X+2X

PACKAGE CONTENT

U	V
	
4X	14X

Step 1

B		6
M		4
N		8



Step 2

A		6



Step 3

B		8
C		8
V		2
O		2



Step 4

A		8



Step 5

B		3



Step 6

A		3
O		2



Step 7

B		4
C		4
V		12
O		12



Step 8

A		4



Step 9

B		8



Step 10

A		4
O		4



Step 11

A		4
O		4



Step 12

C		4
O		4



Step 13

N		8



Step 14

B		8
C		8



Step 15

B		2
M		2
N		4



Accessory M should be flush with the edge of the 15th plate.

Step 16

B		2
M		2
N		4



Accessory M should be flush with the edge of the 16th plate.

Step 17

B		6
C		4



Step 18

A		6



Step 19

A		4
C		4



Step 20

A		4



Step 21

B		2
C		2



Step 22

B		2
C		2
A		2



Step 23

A		2



Step 24

B		6
C		4



Step 25

A | 6



Step 26

A | 4



Step 27

C		10



Step 28

B		10
L		4
K		8



Step 29



Step 30



Step 31

I		4



Step 32

A		4
N		8



Please note: The wooden cabinet must not be lifted by the tabletop on both sides; it can only be moved horizontally

Step 33

Q		12
R		40



If the wooden cabinet is used with an electric fireplace, there is no need to install Plate No.26 and the 4 accessories "Q".

Step 34

J | 36



Step 35

F		2
G		2
K		16
L		4



Step 36

D		4
E		8
U		4



Step 37

H		4



Step 38

G		2
H		2
K		4



Step 39

F		2
H		2
K		4





Step 40

C		2
P		3

Note: Steps 40 to 42 are for the installation of the electric fireplace. If you have not purchased an electric fireplace, you may skip these steps.



Step 41



Step 42



Place the electric fireplace into the wooden cabinet from the front. For instructions on using the electric fireplace, please refer to the electric fireplace manual.

Step 43

J		2
S		2
S		2



Step 44

S		2
T		2
T		2