



9704 Twin Bed

Assembly Instructions


W11-0720

1 Assembled View




Note: Do not assemble using power tools. This can cause the bolts to be overtightened

2 Parts List



3 Hardware List




9751 Twin Headboard


Assembly Instructions

WII-0720


1 Parts List



A
Headboard
Panel x 1



B
Support
Bars x 2



2 Hardware List



1 M6 x 35mm JCB
x 10



2 Spring Washer
x 10




3 Flat Washer
x 10



4 Allen Key
x 1



Note: Do not assemble
using power tools.
This can cause the bolts
to be overtightened

3 Assemble the Support Bars (B) to the Headboard Panel.



✓ Footboard, Rails & Slats
are packed in separate
Boxes with Bolts.

4 Assemble the Headboard Panel (A) to the Support Bars (B).




9704 Twin Bed

Assembly Instructions

WII-0720


- 4** Fit the Post (D) to the Support Panel (E).

x4



- 5** Bolt the Post & Support Panel (D & E) to the Side Rail (C).

x2




9704 Twin Bed


Assembly Instructions

WII-0720

- 6** Assemble the Side Rail (C) to the Headboard and Footboard Panel (A & B).



- 7** Bolt the assembled Support Panel (E) to the Headboard and Footboard Panel (A & B).




9704 Twin Bed

Assembly Instructions

WII-0720

8 Bolt the Bed Slats (F) to the Side Rail (C).



9 Screw the Bed Slats (F) to the Side Rail (C).

