


ASSEMBLY INSTRUCTION FOR ACME FURNITURE

MODEL#LV00405

Thank you for purchasing the quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and metal hardware. Compare with all parts list to be sure all parts are present. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s) needed.

*****Do not fully tighten screws until fully assembled*****




Attention:


***Some number parts listed on the instruction sheet may not be in parts bag as they may already be assembled. Carefully check parts and packing materials prior to ordering replacements.

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.


























- VI. A Phillips head screwdriver is required for the assembly of this product.



















- VII. Power tools should not be used to assemble this product.




COMPONENT PARTS

DESCRIPTION	PART NAME	QTY(PCS)	DESCRIPTION	PART NAME	QTY(PCS)
①	Table Top 	1	⑬	Back plane 	1
②	Table Bottom 	1	⑭	Metal tube 	1
③	Left side pane 	1	⑮	Metal tube 	1
④	Right side panel 	1	⑯	Metal Door 	1
⑤	Left middle side panel 	1	⑰	Metal Legs 	1
⑥	Mid-side panel 	1	⑱	Drawer Front Panel 	2
⑦	Right middle side panel 	1	⑲	Drawer Side Panel(L) 	2
⑧	Metal tube 	1	⑳	Drawer Side Panel(R) 	2
⑨	Metal tube 	1	㉑	Drawer Back Panel 	2
⑩	Left shelf 	1	㉒	Drawer Bottom Panel 	2
⑪	Right shelf 	1	㉓	Support Panel 	2
⑫	Back plane 	2			

Hardware List



A		Ø8x30mm	Wooden dowel	20 pcs
B		Ø6x35mm	Cam bolt	24 pcs
C		Ø15x11mm	Cam lock	24 pcs
D		Ø30mm	Sticker	24 pcs
E		Ø6x50mm	Screw	14 pcs
F		Ø1/4"x30mm	Bolt	4 pcs
G		Ø1/4"x12mm	Bolt	16 pcs
H		4mm	Allen Key	1 pcs
I			Glue tube	1 pcs
J			Handle	2 pcs
K		Ø4x30mm	Screw	12 pcs
L		Ø3.5x14mm	Bolt	20 pcs
M			Drawer slider	2 pcs
N			Plastic wedge	12 pcs
O		Ø3x17mm	Screw	12 pcs
P		Ø4x8mm	Screw	4 pcs




Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1



E x 8	H x 1
	
Ø6x50mm	4mm





Step 2





Step 3





Step 4




Step 5

A x 4	C x 4
	
Ø8x30mm	Ø15x11mm







Step 6

B x 6	G x 6	H x 1
		
Ø6x35mm	Ø1/4"x12mm	4mm




Step 7





A x 6	C x 6
	
Ø8x30mm	Ø15x11mm




Step 8









Step 9

A x 6	E x 6	G x 2	H x 1
			
Ø8x30mm	Ø6x50mm	Ø1/4"x12mm	4mm






Step 10

A x 4	C x 4	F x 2	H x 1
			
Ø8x30mm	Ø15x11mm	Ø1/4"x30mm	4mm





Step 11

G x 4	H x 1
	
Ø1/4"x12mm	4mm




Step 12


D x 14





Step 13



Step 14




Step 15



G x 4
Ø1/4"x12mm

H x 1
4mm

Step 16






N x 12


O x 12
Ø3x17mm

P x 4
Ø4X8mm


Step 17



Step 18



Step 19




Step 20

K x 4




Ø4x30mm




x2pcs

Step 19

C x 10



x2pcs





Step 20

M x 2




L x 8




x2pcs

Step 21

D x 10



Step 22



Step 23

