


















# PORTHOS

## H O M E

<p>A*1</p> 	<p>G*1</p> 	<p>1</p> <p>Please do tighten bolts 70%</p> 	<p>2</p> <p>Please do not tighten bolts until they are on right position</p> 	<p>3</p> 
<p>B*1</p> 	<p>H*8</p>  <p>M6*25MM</p>	<p>4</p> 	<p>5</p> 	<p>6</p> 
<p>C*1</p> 	<p>I*8</p>  <p>M6*20MM</p>			
<p>D*4</p> 	<p>J*4</p>  <p>M6*35MM</p>			
<p>E*1</p> 	<p>K*4</p>  <p>M6*18MM</p>			
<p>F*1</p> 	<p>L*1</p> 