


# E-KING/C-KING BED

## ASSEMBLY INSTRUCTIONS


### BOX #1

A. HEADBOARD 1PC  
B. FOOTBOARD 1PC




### BOX #2




C. SIDE RAIL 2 PCS  
D. BED SLAT 3 PCS  
E. LEG SUPPORT 6 PCS  
BED HARDWARE BOX\*



BED ASSEMBLED




### BED HARDWARE PACKED IN BOX #2


1	ALLEN BOLT (6x40mm)		7 PCS
2	WOOD SCREW (8x30mm)		7 PCS
3	ALLEN KEY		1 PC

TOOL REQUIRED : PHILLIPS HEAD  
SCREWDRIVER (NOT PROVIDED)

YOUR BOX  
MAY CONTAIN  
EXTRA HARDWARE




### STEP 1 :




# E-KING/C-KING BED ASSEMBLY INSTRUCTIONS

## STEP 2 :



## STEP 3 :




## STOP :



IF USING BED FRAME WITH ADJUSTABLE MATTRESS BASE, SKIP TO APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT.  
IF USING BED FRAME WITH STANDARD BOX SPRING OR FOUNDATION CONTINUE TO STEP 4.


## STEP 4 :



# E-KING/C-KING BED

## ASSEMBLY INSTRUCTIONS

### STEP 5 :




### INSTRUCTIONS FOR ADJUSTING LEVELER :

Position the bed in your space and locate the leveler under each leg support (E).

Turn the leveler counter-clockwise to extend the leveler and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the bed slat support .



### MAINTENANCE INSTRUCTION :

- Remove box spring and mattress before moving your bed.
- Lift your bed when moving it. Dragging can damage the leg support.
- Readjust levelers after moving your bed.

# E-KING/C-KING BED

## APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT

AN ADJUSTABLE MATTRESS BASE IS A FREESTANDING MATTRESS SUPPORT THAT SITS WITHIN THE PERIMETER OF THE BED FRAME.

IF USING THIS BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION THESE INSTRUCTIONS DO NOT APPLY.

PRE-ASSEMBLED SIDE RAIL CLEATS OBSTRUCT ADJUSTABLE BASE INSTALLATION AND OPERATION. FOLLOW THESE INSTRUCTIONS TO REMOVE THEM.


### THE FOLLOWING PARTS ARE NOT REQUIRED FOR ADJUSTABLE MATTRESS BASE INSTALLATION:

D. BED SLAT 3 PCS  
E. LEG SUPPORT 6 PCS

1. ALLEN BOLT (6x40mm) 7 PCS  
2. WOOD SCREW (8x30mm) 7 PCS

### STEP 1:

USE ALLEN KEY (3) TO UNSCREW ALLEN BOLTS AND REMOVE PRE-ASSEMBLED SIDE RAIL CLEATS.



NOTE: YOU MAY WISH TO RETAIN UNUSED PARTS IF IN THE FUTURE YOU INTEND TO USE THE BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION.