


ASSEMBLY INSTRUCTIONS

PLEASE READ BEFORE ASSEMBLING!


Tip #1: Make sure you've taken all the pieces and hardware out of its packaging before discarding the box.

Tip #2: Using page 2 and/or page 3 of instruction manual make sure all pieces and hardware are accounted for.

Tip #3: Read manual before assembling, it helps!

















PARTS IDENTIFICATION



(1)	1pc	(7)	1pc
(2)	1pc	(8)	1pc
(3)	1pc	(9)	1pc
(4)	1pc	(10)	1pc
(5)	1pc		
(6)	1pc		


HARDWARE IDENTIFICATION



A		L29	19pcs
B		Ø15	19pcs
C		Ø8x25	12pcs
D		Ø22	13pcs
E		Ø22	4pcs
F		Ø7x58	6pcs
G		Ø8xØ16x2	6pcs
H		Ø16	7pcs
I		197x5x1	1pc
J		Φ 8x40	1pc
K		12x12x1	2pcs
L		Φ 5x40	1pc
M		Φ 4x25	1pc



STEP1


STEP2






STEP3


STEP4






STEP5


STEP6






STEP7


STEP8





STEP9

STEP10




ANTI-TIPPING STRAP INSTRUCTIONS

HARDWARE (INCLUDED) :



DRYWALL ANCHOR $\varnothing 8 \times 40$ X 1PC



METAL BRACKETS $12 \times 12 \times 1$ X 2PCS



DRYWALL SCREW $\varnothing 5 \times 40$ X 1PC




STRAP $197 \times 5 \times 1$ X 1PC



FLATHEAD SCREW $\varnothing 4 \times 25$ X 1PC

TOOLS NEEDED (NOT INCLUDED) :




DRILL & DRILL BIT



LIGHT HAMMER


Note: Hardware included only compatible with standard drywalls.

STEP 1




1. Find spot on wall 1" below top of item.
2. Using a drill bit slightly thinner than anchor, drill hole into drywall.

STEP 2




1. Use a light hammer to tap anchor into hole.
2. Anchor should fit snugly. If hole is too small, drill again to increase hole size. Do not force anchor into wall.

STEP 3



1. Insert drywall screw into metal bracket and into drywall anchor.
2. Insert flathead screw into second metal bracket and into back of item along top edge.

STEP 4



1. Insert strap thru bracket attached to wall, then thru bracket on item, and into head of strap.
 2. pull lightly til strap stops.
- Assembly is complete.