


ASSEMBLY INSTRUCTIONS


30 INCH BATH VANITY (COMBO)




Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.

Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"



* Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!
* Please assemble on a clean soft surface to avoid damage.




+



Tools Required



(Not included)



(Not included)

IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE



**Please do not return this product to the retailer!!
We are able to assist you in ANY way**

If you find that you have any trouble with assembly or
missing or damaged parts please contact the seller







Before Installation

Important – Please read these instructions fully before starting assembly


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions















	Insert Cam Ball into hole as shown in diagram A.
	Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the cam Lock to be misaligned and unable to interlock properly.
	Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.
	Connect the panels together.
	Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.
	To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i>

Detail View - BATH VANITY




Identifying the Hardware -Identify the hardware using the illustrations below.













Part List - N817P288915B/G/W

1		2	
	Side Panel (L) - 1pc		Side Panel (R) - 1pc
3		4	
	Bottom Panel - 1pc		Front Bar - 2pcs
5		6	
	Upper Rear Bar - 1pc		Back Panel - 2pcs
7		8	
	Drawer Face - 2pcs		Drawer Left Panel - 2pcs
9		10	
	Drawer Right Panel - 2pcs		Drawer Back Panel - 4pcs
11		12	
	Drawer Bottom Panel - 4pcs		Drawer Left Panel - 2pc
13		14	
	Drawer Right Panel - 2pcs		Drawer Connect Panel - 2pcs

Part List - N817P288915B/G/W


15	 <p>Sink - 1pc</p>	

Hardware List - N817P288915B/G/W



A  ø6x35mm	B  ø14.5x9.5mm	C  ø6x30mm
Three in one bolts - 39pcs	Three in one lock - 39pcs	Wood dowel - 13pcs
D 	E  ø3x12mm	F  ø3x15mm
Handle 2pcs	Handle screw - 7pcs	Round head screw - 19pcs
G  ø4x20mm	H  ø4x25mm	I  ø4x35mm
Flat head screw - 2pcs	Flat head screw - 17pcs	Flat head screw - 2pcs
J 	K  ø1/4"x16x1mm	L 
Plastic stopper - 2pcs	Washer - 9pcs	Tipover Restraints - 2pcs

STEP 1

A




14pcs




STEP 2


C




12pcs




STEP 3




B
7pcs



STEP 4




B
7pcs




STEP 5

F




18pcs




STEP 6

A




24pcs




STEP 7


H



16pcs




STEP 8




STEP 9

B




8pcs





STEP 10


B





16pcs





STEP 11




D

2pcs
E

6pcs

STEP 12




STEP 13



STEP 14

Install the sink on the cabinet with glue.
Let stand for 24 hours.



* Silicone glue is not included
in the package to comply
with safe regulations in certain
shipping conditions.