


ASSEMBLY INSTRUCTION

N817P397507N

N817P397508N

N817P296126W



Before Installation


Important-Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.


Cam Lock Assembly Instructions

Diagram A




Insert Cam Bolt into hole as shown in diagram A.

Diagram B




Make sure not to insert the Cam Bolt:
Too deep as shown in figure B as this will cause
the Cam Lock to be misaligned and unable to
interlock properly.

Diagram C




Also avoid inserting the Cam Bolt too close to
the surface of the hole as shown in figure C, as
this will cause the Cam Lock to be too
loose, and not interlock properly.



Connect the panels together.




Insert the Cam Lock so the side opening fits
over the head of the Cam Bolt.














To tighten the Cam Lock, turn it clockwise on
half a turn with a flat screwdriver.


*Do not use an automatic screwdriver as it may
bend or break if too much power is imposed.




Box 1 : N817P397507N

		
② x 1	③ x 1	⑤ x 1
		
⑥ x 1	⑦ x 1	⑨ x 1
		
⑩ x 1	⑪ x 1	⑫ x 1
		
⑬ x 1	⑭ x 1	


Box 2 : N817P397508N






① x 1



④ x 1





⑧ x 1



⑬ x 2

⑭ x 5




⑮ x 2



⑯ x 5

⑰ x 1

⑱ x 4



⑲ x 1

⑳ x 1














㉑ x 2

Box 2 : N817P397508N


(22) x 4	(23) x 2	(24) x 2
(25) x 2	(26) x 2	(27) x 2
(28) x 1	(29) x 1	(30) x 1
(31) x 1	(34) x 2	

Box 3 : N817P296126W




Box 2 : N817P397508N

			
A x 53+3	B x 53+3	C x 16+2	D x 5
			
E x 5	F x 64+3	G x 4	H x 1
			
J x 18	K x 1	L x 3	M x 49+2
			
N x 4	O x 8	P x 8	Q x 16+1
			
R x 4	S x 2		








Step 1



Step 2



Step 3









D x 1

E x 1

M3.5x14mm
F x 6

Step 4






D x 3



E x 1

M3.5x14mm
F x 12



Step 5





Step 6




Step 7




Step 8




Step 9





Step 10






Step 11






Step 12




Step 13





Step 14




Step 15



Step 16





Step 17





M3.5x14mm
F x 16

Step 18




To adjust the vertical height.

Loosen the four screws "c" on both hinges. Two of them are usually in slotted holes which allows you to adjust up or down by a few mm. Then tighten back up.



To adjust depth.




Loosen screw "a" and adjust door, if the door can not be adjusted, please loosen screw "b", then try again. Tighten screw "a" and "b".





To adjust side ways.

Turning the screw "b" on BOTH hinges on each door.








Step 19




x2




Step 20





Step 21





M3.5x14mm
F x 6









Step 22








Step 23




Step 24




Step 25




Step 26




M3.5x14mm
F x 4



Step 27



Step 28

