


ASSEMBLY INSTRUCTION

BATHROOM VANITY



Before Installation


Important-Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.


- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions


		Diagram A Insert Cam Bolt into hole as shown in diagram A.
		Diagram B Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.
		Diagram C Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.
		Connect the panels together.
		ARROW SIGN Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.
		To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. *Do not use an automatic screwdriver as it may bend or break if too much power is imposed.




Part list




① × 1




② × 1




③ × 1




④ × 1




⑤ × 1




⑥ × 1




⑦ × 1




⑧ × 1




⑨ × 1















⑩ × 1




⑪ × 1




⑫ × 4


		
⑬ × 1	⑭ × 1	⑮ × 1
		
⑯ × 1	⑰ × 2	⑱ × 2
		
⑲ × 4	⑳ × 4	㉑ × 1
		
㉒ × 1	㉓ × 1	㉔ × 4




②⑤ × 4




②⑥ × 2




②⑦ × 2




②⑧ × 1




②⑨ × 3




③① × 3




③① × 3




③② × 3




③③ × 1














③④ × 3




③⑤ × 1




Hardware list

					
M6×35mm A × 68+2	Φ15×10mm B × 68+2	Φ6×30mm C × 16+2	M3×12mm D × 34+2	M3.5×12mm E × 48+2	M4×25mm F × 16+2
					
M4×35mm G × 52+2	Φ8×30mm H × 54+2	I × 8	J × 6	K × 4	M4×18mm L × 7
					
M × 7	N × 2	O × 1	M6×60mm P × 4	Q × 2	M4×45mm R × 12+2
					
M7×50mm S × 1	T × 8	U × 8	M6×50mm V × 8	M4 W × 1	M4×12mm X × 20+2
					
Y × 4					


Step 1







Step 2







J-1 × 3







J-1 × 3




Step 3




Step 4






Step 5






Step 6




Step 7



Step 8



Step 9






M4×35mm

G × 4

Step 10





M4×35mm



G × 2







Φ8×30mm

H × 2




Step 11




Step 12



Step 14



Step 15






M6×35mm

A × 14

Step 16






Φ15×10mm

B × 6




Φ8×30mm


H × 6





Step 17






Step 18





Step 19





Step 20




Step 21



Step 22



Step 23







M4×45mm

R × 12

Step 24





T × 8



U × 8



M6×50mm


V × 8




M4

W × 1





Step 25








Step 26




Step 27




Step 28




Step 29




SETTING S DOORS



If the hinge holes are not aligned, you can try adjusting the front and rear hinges.



If the door gap is large, you can adjust the hinges left and right




×4



M3.5×12mm

E × 16

Step 30




×4



M3.5×12mm

E × 8



I × 4




M4×18mm

L × 2




M × 2


Step 31




SETTING S DOORS



If the hinge holes are not aligned, you can try adjusting the front and rear hinges.



If the door gap is large, you can adjust the hinges left and right




×4




M3.5×12mm

E × 16


Step 32



×3



×3



M6×35mm

A × 12



M4×35mm

G × 12




M4×18mm

L × 3




M × 3



Step 33




x3





x3




Step 34





×3





Step 35






Step 36




Step 37



Step 38



Step 39



Step 40

