


Greenhouse

Assembly Instructions



IMPORTANT

You must read these instructions carefully before you start to assemble this greenhouse.

Please ensure that you find all parts in the carton box in the correct type and quantity as mentioned in the list illustrated in every page accordingly.

Please carry out the steps in the order set out in these instructions.

Do not tighten the steps in the greenhouse until completing on the assembly of the polycarbonate panels.

Keep these instructions in a safe place for future reference.

SAFETY ADVICE

We strongly recommend the use of work gloves during assembly.
Do not attempt to assemble the greenhouse in windy or wet conditions,
Do not touch overhead power cables with the aluminum profiles.
Always wear shoes and safety goggles when working with extruded aluminum.
Dispose of all plastic bags safely-keep them out of reach of small children.
The greenhouse must be positioned and fixed on a flat level surface.
Do not lean against or push the greenhouse during construction.
Keep children away from the assemble area.
Do not position your greenhouse in an area exposed to excessive wind.
Do not attempt to assemble this greenhouse if you are tired ,have taken drugs or alcohol or if you are prone to dizzy spells.
If using a step ladder or power tools ensure that you follow the manufactures safety advice.
Hot items such as recently used grills, blowtorches etc.must not be stores in the greenhouse.
Ensure there are no hidden pipes or cables in the ground before inserting the pegs.

GENERAL ADVICE





This is a multi-part assembly, Allow at least 300 minutes for assembly.
Selecting a site-choose a sunny level position away from overhanging trees.
If you are fixing your greenhouse directly to a solid concrete foundation use the pre drilled holes in the metal base supplied.
The component parts should be checked and laid out close at hand.
Keep all small parts(screws etc)in a bowl so they do not get lost.
Note that the door is hinged on the right hand side and therefore opens tothe right.
Keep roof clear of snow and leaves.





CARE & MAINTENANCE

When your greenhouse needs cleaning, use a mild detergent solution and risen with cols clean water.
Do NOT use acetone, abrasive cleaners or other special detergents to clean the clear panels.

TOOLS & EQUIPMENT REQUIRED

Silicone sealant & applicator bradawl phillips screwdriver step ladder.
Tape measure large hammer scissors
Work gloves Drill spirit level Lubricant see over for cantents plastic or rubber mallet 0.08" metal drill bit
If help is required seek professional advise within store.


PART	NO.	QTY.
	D1	1
	D4	1
	D2	1
	D3	3
	W1	2
	W2	4
	W3	2
	W4	2
	4	2
	4-1	2
	5	1
	6	1
	7	4
	16	4
	8	4
	9	2
	10R	1
	10L	1
	19	10
	20	10
	12	4
	15	3
	13	1

PART	NO.	QTY.
	14	1
	22	12
	23	4
	17	2
	18	1
	25	4
	26	2
	B1	8
	B3	4
	B4	4
	B5	4
	B6	2
	B7	2
	B10	2
	B11	2
	B12	1
	T2	10
	T1	5
	S2	17
	S5	2
	S6R	2
	S6L	2
	S7R	1
	S7L	1
	S8	2
	S10	2


PART	NO.	QTY.
	F1	10
	F2	8
	F4	196
	F6	2
	F7	32
	F9	2
	F8	2
	S9	2

PC BOARDS	P1	3
	P2	2
	P3	4
	P4R	2
	P4L	2
	P5	1
	P6	1
	P7	1
	P8	12
	P9	10
	P10	2

SUMMARY STATEMENT FOR POLYCARBONATE PANEL






The UV-protected side of the sheet is covered with transparent film and must face towards the sun.




"hexagonal screw" installation

Place the "hexagonal screw" into the groove, turn clockwise until it stops turning.
Adjust the "hexagonal screw" by hand and twist so threads fix it in place.
Place other parts on "hexagonal screw" and assemble nut.


PART	NO.	Qty.
	D1	1
	D4	1
	D2	1
	D3	3
	F1	10





WINDOW




PART	NO.	Qty.
	W1	2
	W2	4
	W3	2
	W4	2
	S8	2
	S9	2
	F2	8
	F8	2
	F9	2








PART	NO.	Qty.
	8	4
	17	2
	B11	2
	B12	1
	F7	24



PART	NO.	Qty.
	4	2
	4-1	2
	5	1
	6	1
	8	2
	17	1
	B10	2
	F7	8
	F4	64



F4(1PCS) F4(2PCS)



F4(1PCS)/ 10R and 10L





F4(2PCS)




F4(1PCS)


10R


10L




PART	NO.	Qty.
	7	4
	10R	1
	10L	1
	F4	8










PART	NO.	Qty.
	S2	2
	12	2
	B1	4
	F4	4









PART	NO.	Qty.
	B4	2
	B6	2
	B5	4
	F4	24
	18	1
	26	2



F4(2PCS)





PART	NO.	Qty.
	19	10
	20	10
	F4	52



Remark:


Please insert 4 screws in the two profile aluminum 20 beside the windows and the others profile 20 insert 3 screws .

F4(5PCS)






F4(2PCS)





PART	NO.	Qty.
	S2	12





PART	NO.	Qty.
	25	4
	S5	2
	S6L	2
	S6R	2
	S7L	1
	S7R	1
	S10	2

