


ASSEMBLY INSTRUCTIONS

36 INCH-BATH VANITY-CABINET


SKU - BW00349





Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED



*Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe!!!
* Please assemble on a clean soft surface to avoid damage.




+



Tools Required




(Not included)



(Not included)

IMPORTANT:
PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE



**Please do not return this product to the retailer!!
We are able to assist you in ANY way**

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.










Before Installation

Important- Please read these instructions fully before starting assembly


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions


		Diagram A Insert Cam Ball into hole as shown in diagram A.	
		Diagram B Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the cam Lock to be misaligned and unable to interlock properly.	
		Diagram C Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.	
			Connect the panels together.
			ARROW SIGN Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.
			To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i>

Detail View




Part Lists BW00349

1




Side Panel (L) - 1pc

2




Side Panel (R) - 1pc

3




Frame Bottom - 1pc

4




Front Crossbar Top - 1pc

5




Front Crossbar Mid - 1pc

6




Front Crossbar Bottom - 1pc

7




Rear Crossbar Bottom - 2pcs

8




Rear Crossbar Mid - 2pcs

9




Panel Mid (L) - 1pc

10




Panel Mid (R) - 1pc

11




Adjustable Shelf - 2pcs

12




Top Drawer Front - 1pc

13



Top Drawer Panel Side 1 (L) - 1pc


14



Top Drawer Panel Side 1 (R) - 1pc


Part Lists BW00349

15




Top Drawer Panel Rear - 1pc

22




Drevent Studing - 1pc

16




Panel Bottom 1- 1pc

23




Vertical learning Compartment - 1pc

17




Bottom Drawer Front - 1pc

24



Door Cabinet - 1pc

18




Bottom Drawer Panel Side (L) - 1pc

25



Doc Bar (L) - 1pc

19




Bottom Drawer Panel Side (R) - 1pc

26




Doc Bar (R) - 1pc

20




Bottom Drawer Panel Rear - 1pc

27




Horizontal Bar 1 - 2pcs

21



Panel Bottom - 1pc


28



Horizontal Bar 2 - 2pcs



















Part Lists BW00349

29




Lavabo - 1pc

Hardware Lists BW00349

A  $\varnothing 8 \times 20 \text{mm}$ Wood dowel (36pcs)	B  $\varnothing 6 \times 32 \text{mm}$ Three in one bolts (22pcs)	C  $\varnothing 14.5 \times 9.5 \text{mm}$ Three in one locks (22pcs)
D  $\varnothing 8 \times \varnothing 4 \times 30 \text{mm}$ Round head screw (6pcs)	E  K4mm Allen key (1pc)	F  4pcs 24pcs Damping hinge (4sets)
G  M6 x 45mm Head bolt (22pcs)	H  M6 x 13mm Square Nut (8pcs)	J  Handle(2pcs)
K  $\varnothing M4 \times 20 \text{mm}$ Handle screw (3pcs)	L  Lid Support (1pc)	M  $\varnothing 8 \times \varnothing 3.5 \times 15 \text{mm}$ Flat head screw (4pcs)
N  $\varnothing 8 \times \varnothing 3.5 \times 12 \text{mm}$ Round head screw (8pcs)	O  Shelf Pin (8pcs)	P  $\varnothing 10 \times 10 \text{mm}$ Plastic Canopy (4pcs)
Q  Handle(1pc)	S  $\varnothing 8 \times \varnothing 3.5 \times 15 \text{mm}$ Round head screw (2pcs)	R  Anti fall Hardware (2sets)

STEP: 1



A



4PCS

G




6PCS

H



6PCS

STEP: 2



A




1PC

G




1PC

STEP: 3




B



6PCS

STEP: 4



A



9PCS

C




3PCS



G




6PCS




STEP: 5




A	
	1PC
G	
	1PC

STEP: 6




A	
	9PCS
C	
	3PCS
G	
	6PCS

STEP: 7



G




2PCS

H




2PCS

STEP: 8



B




4PCS

STEP: 9


C




4PCS



STEP: 10



STEP: 11




D



2PCS

STEP: 12



J





2PCS

K




2PCS


STEP: 13




2PCS



4PCS





1PC




2PCS

STEP: 14



8PCS

STEP: 15




M




2PCS

STEP: 16




B



4PCS

STEP: 17




C



4PCS

STEP: 18



D





4PCS

P




4PCS


STEP: 19



STEP: 20




STEP: 21




STEP: 22

B



8PCS



STEP: 23

A




4PCS


C



2PCS



STEP: 24



A




4PCS

C



2PCS

STEP: 25



A




4PCS

C



4PCS

STEP: 26



F




2PCS

F



4PCS

STEP: 27



Q



1PC

K





1PC

STEP: 28


F




8PCS




Use the screws to adjust up or down




Use the screws to permanent





Use the screws to adjust left or right



Use the screws to adjust in or out



STEP: 29




O





8PCS

STEP: 30



STEP: 31





N




8PCS

STEP: 32




R



2SET


STEP: 33

Install the sink on the cabinet with glue.
Let stand for 24 hours




*Silicone glue is not included in the package to comply with safety regulations in certain shipping conditions.


STEP: 34



STEP: 35




HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw
clockwise to move the door further away from
the side of the cabinet
anticlockwise to move the door closer to the
side of the cabinet



② ④ Height adjustment

While supporting the weight of the door, turn the
screws
clockwise to move the door up
anticlockwise to move the door down



③ Forward and back adjustment

