


ASSEMBLY INSTRUCTION

SKU CODE : BW00472
TWIN SIZE FLOOR BED



Bed Type
Twin Standard


Length
75"

Width
38 "

















Thickness
6" max

This set is included 1 boxes, if don't receive full 1 boxes please contact our customer service team.








ASSEMBLY INSTRUCTION
















Part List & Hardware List BW00472

<p>① x 2</p>  <p>Leg</p>	<p>② x 1</p>  <p>Leg</p>
<p>③ x 1</p>  <p>Leg</p>	<p>④ x 1</p>  <p>Side rail</p>
<p>⑤ x 1</p>  <p>Side rail</p>	<p>⑥ x 1</p>  <p>Railing frame</p>
<p>⑦ x 1</p>  <p>Top cap</p>	<p>⑧ x 2</p>  <p>Railing frame</p>
<p>⑨ x 2</p>  <p>Top cap</p>	<p>⑩ x 2</p> 
<p>⑪ x 1</p>  <p>Railing frame</p>	<p>⑫ x 1</p>  <p>Top cap</p>
<p>⑬ x 1</p>  <p>Vertical support</p>	<p>⑭ x 1</p>  <p>Back Panel</p>
<p>⑮ x 1</p>  <p>Side Panel</p>	<p>⑯ x 1</p>  <p>Side Panel</p>

Part List & Hardware List BW00472

<p>(17) x 1</p>  <p>Divider Panel</p>	<p>(18) x 1</p>  <p>Bottom Panel</p>
<p>(19) x 1</p>  <p>Front Panel</p>	<p>(20) x 1</p>  <p>Crossbar</p>
<p>(21) x 7</p>  <p>Support Leg</p>	<p>(22) x 3</p>  <p>Slats</p>
<p>(0) x 4</p>  <p>Slats</p>	


Hardware List BW00472

No.	OUTLOOK	DESC	QTY
(A)		Dowel Ø10*40mm	37
(B)		Bolts 1/4"*15mm	04
(C)		Bolts 1/4"*25mm	02
(D)		Bolts 1/4"*30mm	03
(E)		Bolts 1/4"*70mm	03
(F)		Bolts 1/4"*80mm	02
(G)		Bolts 1/4"*90mm	26
(H)		Cross dowel 1/4"*13mm	28
(I)		Hex bolts 1/4"*15mm	06
(J)		Round Head Screw #8*25mm	09
(K)		Screws #8*30mm	29
(L)		Screws #8*35mm	10
(M)		Allen key 60*22*4mm	02


ASSEMBLY TOOLS REQUIRED (NOT INCLUDED)



STEP 1




(A)		08
(G)		06
(H)		06







Note: Do not overtighten the bolts to ensure easier assembly in the next step.

STEP 2





COMPLETE



(A)		08
(G)		06
(H)		06



Note: Do not overtighten the bolts to ensure easier assembly in the next step.

STEP 3




(A)		04
(K)		06




STEP 3.2

STEP 3.1


STEP 4

(A)		08
(G)		12
(H)		12




Note: Do not overtighten the bolts to ensure easier assembly in the next step.




STEP 5




(A)		04
(F)		02
(G)		02
(H)		04









STEP 6

(C)		02
(E)		03
(I)		02






STEP 7

(A)		05
(K)		09





STEP 8

(L)		07
-----	---	----




STEP 9


(L)		03
-----	--	----





STEP 10





Rotate the assembly from Step 8 as described and continue.







STEP 11

(B)		04
(I)		04



STEP 12

(D)		03
(K)		14



Check and fully tighten all bolts in the assembly steps to ensure a solid structure.

COMPLETED

