




Kitchen Cart


SKU N707P409085

SKU N707P409086


Assembly instructions-Please keep for future reference




Important-Please read these instructions fully before starting assembly




QUICKFIT: Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.





LOCK: When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.



Quickfit head should be in the centre of the cam lock when the two panels are joined. Cam lock should be inserted before quickfit.




Turn cam lock clockwise to tighten.










friendly reminder








To avoid errors and confusion during the installation of accessories, use the type and quantity of hardware accessories according to the installation procedure described in the instructions. First, unroll the accessories bag and lay out the hardware accessories, cut holes in the side, and take out the hardware accessories

Assembly Instructions





BOX:N707P409085








NO.	PARTS	QTY
②		x1
NO.	PARTS	QTY
⑤		x1
NO.	PARTS	QTY
⑥		x1
NO.	PARTS	QTY
⑦		x1
NO.	PARTS	QTY
⑪		x1
NO.	PARTS	QTY
⑰		x1
NO.	PARTS	QTY
⑱		x1







NO.	PARTS	QTY
⑱		x1
NO.	PARTS	QTY
⑳		x1
NO.	PARTS	QTY
㉒		x1
NO.	PARTS	QTY
㉓		x1
NO.	PARTS	QTY
㉔		x2
NO.	PARTS	QTY
㉕		x2
NO.	PARTS	QTY
㉘		x2

BOX:N707P409085








NO.	PARTS	QTY
31		x1
NO.	PARTS	QTY
34		x1


BOX:N707P409086

NO.	PARTS	QTY
①		x1
NO.	PARTS	QTY
③		x1
NO.	PARTS	QTY
④		x1
NO.	PARTS	QTY
⑧		x1
NO.	PARTS	QTY
⑨		x1
NO.	PARTS	QTY
⑩		x1
NO.	PARTS	QTY
⑫		x1









NO.	PARTS	QTY
⑬		x2
NO.	PARTS	QTY
⑭		x1
NO.	PARTS	QTY
⑮		x1
NO.	PARTS	QTY
⑯		x1
NO.	PARTS	QTY
⑰		x1
NO.	PARTS	QTY
⑳		x1
NO.	PARTS	QTY
㉑		x1

BOX:N707P409086

NO.	PARTS	QTY
(27)		x1
(29)		x2
(30)		x1
(32)		x1
(33)		x1
(35)		x1
(36)		x2



NO.	PARTS	QTY
(37)		x1

Hardware:N707P409086










<p>A x42+2 Ø6x35mm</p> 	<p>B x42+2 Ø15x10mm</p> 	<p>C x24+2 Ø6x30mm</p> 	<p>D x12+1 M4x40mm</p> 	<p>E x24+2 M4x30mm</p> 	<p>F x20+2 M4x16mm</p> 	<p>G x48+2 M3x12mm</p> 	
<p>H x28+2 M4x20mm</p> <p>black</p> 	<p>I x4</p> 	<p>J x2</p> 	<p>K x3</p> 	<p>L x2</p> 	<p>M x6</p> 	<p>N x1</p> 	
<p>O x2</p> 	<p>P x2</p> 	<p>Q x6</p> 	<p>R x1</p> <p>R1 R2</p> 	<p>S x2</p> 	<p>T x6</p> <p>M4x14mm +1</p> 	<p>U x2+1 Ø8x30mm</p> 	
<p>V x8+1</p> 	<p>W x4</p> 	<p>X x80+4 M3x14mm</p> 	<p>Y x12+1 M3x16mm</p> 	<p>Z x8 L=320mm</p> <p>Z1 Z2</p> 			
							

















Assembly Steps


1




2











D x4
M4x40mm




B x1
Ø15x10mm




C x1
Ø6x30mm









B x1

Ø15x10mm




C x1

Ø6x30mm





B x1


Ø15x10mm




C x1

Ø6x30mm














E x4
M4x30mm




B x2
Ø15x10mm








C x8
Ø6x30mm



D x8
M4x40mm



F x20
M4x16mm











J x2





K x3











Y x12



M3x16mm













X x4
M3x14mm










I x2

















X x4
M3x14mm




X x4
M3x14mm





V x4



X x8
M3x14mm




T x2




W x4








Loosen this screw and push up/down for a slight up-down adjustment of the door.





Loosen this screw for a slight left-right adjustment of the door.



Loosen this screw and push forward/backward for a slight front-back adjustment of the door.




X x 16
M3x14mm




A x 8
Ø6x35mm





x2





E x8
M4x30mm





x2

B x8
Ø15x10mm


T x2




x2





When installing the slide rail, it should be inserted at the same time, and then pushed together












x2








x2













V x4




When installing the slide rail, it should be inserted at the same time, and then pushed together



X x24
M3x14mm













M x6






A x2
Ø6x35mm













OR



OR



Assembly Instructions

Caution : You must read this before you proceed

Care & Maintenance

-   ● Not for commercial use. For residential use only.
-   ● Furniture may scratch floors. We recommend using furniture pads to protect your floors.
-   ● Do not put hot items directly on furniture surface.
-   ● Do not clean furniture with harsh cleansers or polish.
-   ● Do not place furniture under direct sunlight.
-   ● Do not place furniture near heating or cooling vents.
-   ● Do not write on furniture without a padded barrier to protect the surface.
-   ● Do not place furniture outside . For indoor use only.
-   ● Stains may be removed with mild soap solution and damp cloth.
-   ● Children should not climb or jump on the furniture.
-   ● Dust and pick-up spills using a clean, non-colored, lint-free cloth.