CARE AND MAINTENCE

Wipe clean with a soft, dry cloth. The seat board can be cleaned with a mild cleaner. Test the cleaning method on a hidden area before using them over the entire area.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item.
- * This item should be assembled on a soft surface to prevent scratching the finished product during assembly.
- * This item may require periodic tightening.
- * Do not tighten bolts until completely assembled.


Part List and Hardware List

Piece	Description	Picture	Quantity
А	TABLE TOP		1 X
В	LEG-1		2 X
С	LEG-2		2 X
HW1	Hex Socket Bolt 5/16"-18*1- 1/4"	(C)	16 X
HW2	Allen Key 4mm		1 X



Model# DSK6400

Product Dimensions: 45"W*20"D*32-1/2"H





Weight Capacity: 25 lbs


Warning: Do not stand on the product Warning: Do not over torque bolts

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time:15 minutes.

Tools Required for Assembly (included):Allen key.



Step 1: Assembly 2*Leg-1 (B) to the underneath of the table top (A) in diagonal position facing front left. Using Allen key (H2) to lock with 8*Hex Socket Bolts (HW1). Repeat this process to assembly rest 2*Leg-2 (C). As picture.

Step 2: Straighten up the assembled product, Assembly is completed.