
Assembly Instructions

Caution: You must read this before you proceed

Please look in the Seat Panel for hardware packs and legs.

Chair



Caution: This Chair is NOT a TOY.


Keep your child/children at bay during the assembly process.

Whenever moving/lifting the Chair and to prevent damage to the Chair, two adults are required to execute these actions.

Part List			
Label	Picture	Description	Qty
А		Seat Panel	1
В		Seat Support Bar	2
С		Back Support Bar	1
D		Left Leg Panel (with Pre-installed Levellers)	1
E		Right Leg Panel (with Pre-installed Levellers)	1
F		Back Cushion	1
G		Seat Cushion	1
<u>Hardware</u>			
No.	Picture	Description	Qty
1)		Bolt (M8x35mm)	11
2		Allen Key	1

Assembly Preparation

Before Beginning Assembly:





 \boxtimes Read instructions, cover to cover.



☐ Have 2 adults on hand for assembly.




□ Do not assemble on flooring or carpet.






Save all packaging until finished.


<u> Assembly Steps</u>



This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.



Unpack and place all parts on a clean, non-marring surface.




Place Right Leg Panel(E) on a clean, non-marring surface.

Insert tenons on Seat Support Bar(B) and Back Support Bar(C) into the mortises of Right Leg Panel(E) as shown above.


Attach Seat Support Bar(B) and Back Support Bar(C) to Right Leg Panel(E) using Bolts($\widehat{(1)}$) with Allen Key($\widehat{(2)}$) as shown in picture above.

Do not fully tighten the Bolts.




Attach Left Leg Panel(D) to the frame using Bolts(1) with Allen Key(2) as shown in picture above.

Do not fully tighten the Bolts.



Insert Seat Panel(A) into assembled frame, then attach using Bolts(1) with Allen Key(2) as pictured above.

Do not fully tighten the Bolts.



Place the Chair onto a flat, level surface.

Then EXERT pressure, floorwards onto the Chair with both hands.


This pressure will help the Chair reach full alignment at all joints.

In a sequential manner, gradually tighten all Bolts at all joints until evenly secured.

Inspect the Chair and make sure all parts are adequately connected.

Adjust the Levellers until the Chair is level with the ground.

To adjust the Levellers, get assistance from an adult partner to lift/lean and hold the Chair while you are working.



Place Seat Cushion(G) and Back Cushion(F) onto Seat Panel(A), then tie the velcro straps around Seat Cushion(G) as pictured.

Your Chair is ready for use.

This Chair can only be used on a flat, level surface.

Care & Maintenance



Do not put hot items directly on furniture surface



Do not clean furniture with harsh cleansers or polish.



 To obtain the longest lifespan of your outdoor prodcts, minimizing exposure to direct sunlight is recommended.



Children should not climb or jump on the furniture.



Do not write on furniture without a padded barrier to protect the surface.



 To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.



Not for commercial use. For residential use only .



Stains may be removed with mild soap solution and damp cloth.



Dust and pick-up spills using a clean, non-colored, lint-free cloth .