

ASSEMBLY INSTRUCTION




ITEM NO: 194S9588BEG/DGY/GRN/GRY/MDN/YLW-1PB

PUSH BACK RECLINING CHAIR




Legs are stored in the box under the seat.
Please take out for assembly.


NOTE: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.

NO.	DRAWING	QTY	DESCRIPTION
A		1	Seat
B		1	Backrest
C		4	Plastic Leg


Exploded View




STEP 1:





STEP 2:




STEP 3:



STEP 4:





Care instruction for Corduroy furniture:

In order to maintain the original appearance of your Corduroy furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating or heating conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage Corduroy.
- Do not place your upholstered furniture too close to windows, radiators, or vents, and be sure to use windows, radiators, or vents.
- Vacuum or wipe with a cloth regularly to remove dust.



For items used on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.