

## C90263CH ASSEMBLY INSTRUCTION

**W**e believe you will absolutely love your new furniture. Please immediately examine this product carefully. Any request for missing part or damage replacement must be received within 90 days of your receipt of the product. For some reason you want to return the product, please contact us directly before you decide to return your product to the retailer. Our Customer Service team can answer most concerns and can assist you with any questions you may have about your new product.

Please contact us first by emailing [service@casepiece.com](mailto:service@casepiece.com)

Have these ready when you email:

- Item Number
- PO #
- Purchaser Name
- Proof of Purchase
- Description of the problem and/or the Part Number needed

Replacements for missing or damaged parts or hardware are normally shipped within 3 to 5 business days and we thank you for your patient.

The item must be returned in good condition, in original box, with all original proof of purchase, parts and accessories, within the time frame specified by the retailer it was purchased from.

### 90-Day Limited Warranty Statement for Manufacturing Defects

Please read this Limited Warranty carefully. To maintain your Warranty, you will need to comply with the conditions stated here.

This warranty is for manufacturing defects only and does not cover damages as a result of misuse.

1. Our products sold comply with the description contained in this Warranty. All parts and products are warranted 90-Day from the original date of delivery except: parts and products used for commercial, contract, rental trade, institutional, or any other non-residential purposes; parts and products that have not been maintained in accordance with the care recommendations provided; parts and products damaged resulting from the consumer's improper assembly; or parts and products that are damaged or defective due to normal wear and tear.










2. To exercise rights under this warranty, proper documentation, i.e., photography, purchase order number, manufacturer's bar code label, and or any other pertinent information upon request is required. We reserve the right to repair or replace the product within the warranty period based upon the documentation received as support of a claim for consideration. We will not replace or repair any product if improper maintenance, improper handling, or improper use caused the damage. Any product sold from or modified by a Non-Authorized Dealer, Seller or Consumer will void the Warranty.

3. Cost of packaging and shipping to and from us is not covered by the warranty unless expressly arranged by us. This warranty does not extend to furniture that has been exchanged or replaced by us as settlement of an original claim of defective merchandise. This warranty does not extend to furniture that has been moved from delivery location on original purchase order.

We appreciate your business!







# C90263CH ASSEMBLY INSTRUCTION

## HARDWARES LIST

ITEM	DESCRIPTION	DRAWING	QTY
A	MINIFIX CAM LOCK		32 PCS
B	MINIFIX CAM BOLT		32 PCS
C	WOOD DOWEL (M8 x 25MM)		24 PCS
D	WOOD DOWEL (M6 x 25MM)		32 PCS
E	TRUSS M-SCREW (16MM)		8 PCS
F	HANDLE		8 PCS
G	6/8" NAIL		22 PCS
H	PLASTIC STRIP (H SHAPE)		1 PC
I	JCBC M6 x 40MM		16 PCS










# C90263CH ASSEMBLY INSTRUCTION

## HARDWARES LIST

ITEM	DESCRIPTION	DRAWING	QTY
J	M4 ALLEN KEY (65MM)		1 PC
K	JCBC M6 x 60MM		4 PCS
L	SPRING WASHER (M6 x 13MM)		20 PCS
M	FLAT WASHER (M6 x 19MM)		20 PCS
N	TIPPING RESTRAINT		1 PC
O	PAN HEAD SCREW ( M4 x 50MM)		1 PC










# C90263CH ASSEMBLY INSTRUCTION

## PARTS LIST



ITEM	DESCRIPTION	DRAWING	QTY
C1	TOP PANEL		1 PC
C2	LEFT PANEL		1 PC
C3	RIGHT PANEL		1 PC
C4	SUPPORT RAIL		2 PCS
C5	BACK PANEL		2 PCS
C6	TOP DRAWER HEAD		1 PC
C7	DRAWER BACK PANEL		4 PCS
C8	DRAWER BOTTOM PANEL		4 PCS
C9	BOTTOM PANEL		1 PC

# C90263CH ASSEMBLY INSTRUCTION

## PARTS LIST


ITEM	DESCRIPTION	DRAWING	QTY
C10	FRONT TIPPING PANEL		1 PC
C11	BACK TIPPING PANEL		3 PCS
C12	MIDDLE DRAWER HEAD		2 PCS
C13	BOTTOM DRAWER HEAD		1 PC
C14	CORNER RAIL		4 PCS
19	DRAWER LEFT PANEL		4 PCS
20	DRAWER RIGHT PANEL		4 PCS
21	DRAWER BOTTOM SUPPORT RAIL		4 PCS
22	LEG		4 PCS

\*Note: All parts needed are shown in above picture.  
Numbers only indicate the specific parts for easy assembly.


ASSEMBLY TOOLS REQUIRED	
1. Screwdriver (not provide) 	2. Hammer (not provide) 

# C90263CH ASSEMBLY INSTRUCTION

NOTE : - The outer board is for protection of packaging only, not part of furniture. Please throw it before assembly.




## STEP 1



# C90263CH ASSEMBLY INSTRUCTION


## STEP 2



## STEP 3

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.


**x 2**



# C90263CH ASSEMBLY INSTRUCTION


## STEP 4

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.



## STEP 5


**x 4**






# C90263CH ASSEMBLY INSTRUCTION

## STEP 6





## STEP 7




# C90263CH ASSEMBLY INSTRUCTION



## STEP 8




INSIDE VIEW



## STEP 9




INSIDE VIEW




# C90263CH ASSEMBLY INSTRUCTION

## STEP 10




## STEP 11




# C90263CH ASSEMBLY INSTRUCTION


## STEP 12





### STEP 12.1



### STEP 12.2




## STEP 13




# C90263CH ASSEMBLY INSTRUCTION

## STEP 14

Side with color paper must be the same.



## STEP 15




# C90263CH ASSEMBLY INSTRUCTION

## STEP 16

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.


**x 4**



## STEP 17

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.

**x 4**






# C90263CH ASSEMBLY INSTRUCTION

## STEP 18

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.


**x 4**



## STEP 19

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.


**x 4**



# C90263CH ASSEMBLY INSTRUCTION


## STEP 20

**x 4**



## STEP 21


**x 4**






# C90263CH ASSEMBLY INSTRUCTION

## STEP 22




## STEP 23




# C90263CH ASSEMBLY INSTRUCTION

## STEP 24



## STEP 25



**ASSEMBLY COMPLETED**