

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

460332BLK(B1&B2) Twin Workstation Loft Bed

REVISION 0 : 07/31/2025

PAGE 1 OF 22

COASTERFURNITURE.COM



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

50 MINUTES

PARTS IDENTIFICATION



PAGE 2 OF 22

COASTERFURNITURE.COM

COASTER*

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

PARTS IDENTIFICATION

B1 (BOX 1)				
A	LEFT FRONT POST (WITH LABEL "A")		1PC	
В	LEFT BACK POST (WITH LABEL "B")		1PC	
С	RIGHT BACK POST (WITH LABEL "C")		1PC	
D	RIGHT FRONT POST (WITH LABEL "D")		1PC	
E	REAR GUARD RAIL (WITH LABEL "E")		1PC	
F	FRONT GUARD RAIL (WITH LABEL "F")		1PC	
R	DESK SUPPORT FRAME (WITH LABEL "R")		2PCS	
s	LADDER SUPPORT BRACKET (WITH LABEL "S")		1PC	
S 1	CONNECTOR POST SUPPORT (WITH LABEL "S1")		4PCS	
J	LADDER (WITH LABEL "Z")		1PC	



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

PARTS IDENTIFICATION

B2 (BOX 2)

K	DESK SUPPORT BAR (WITH LABEL "K")	1PC
I	RIGHT END GUARD RAIL (WITH LABEL "I")	1PC
M	MESH PANEL (WITH LABEL "M")	1PC
N	CONNECTOR POST (WITH LABEL "N")	2PCS
0	BED SLAT (WITH LABEL "O")	20PCS
I1	LEFT END GUARD RAIL (WITH LABEL "I1")	1PC
T1	LOWER GUARD RAIL (WITH LABEL "T1")	1PC
V1	SMALL SHELF SUPPORT (WITH LABEL "V1")	1PC
V2	BIG SHELF SUPPORT (WITH LABEL "V2")	2PCS
E2	SMALL SHELF (WITH LABEL "E2")	1PC
U	DESK (WITH LABEL "U")	1PC
E1	BIG SHELF (WITH LABEL "E1")	2PCS

COASTER® FINE FURNITURE

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B1(BOX 1) HARDWARE PACK IS LOCATED IN 460332BLK(B1)

1	BOLT 1 (1/4" x 65mm - BLK)	6PCS
2	BOLT 2 (5/16" x 60mm - BLK)	1PC
3	BOLT 3 (1/4" x 36mm - BLK)	6PCS
4	BOLT 4 (1/4" x 37mm - BLK)	10PCS
5	BOLT 5 (1/4" x 30mm - BLK)	12PCS
6	BOLT 6 (1/4" x 27mm - BLK)	12PCS
7	BOLT 7 (1/4" x 22mm - BLK)	1PC
8	BOLT 8 (1/4" x 20mm - BLK)	12PCS
9	BOLT 9 (1/4" x 15mm - BLK)	8PCS
10	BOLT 10 (1/4" x 10mm - BLK)	4PCS
11	ALLEN WRENCH (4mm x 58 mm - WZ)	1PC
12	RATCHET WRENCH (4mm - 110mm - WZ)	1PC

ASSEMBLY INSTRUCTIONS




Helpful Hints

- Before assembling the furniture, please read the instructions on how to use ratchet, it will help you to assemble the furniture quickly.
- Please don't throw away the ratchet in case you may need to use in future.


How To Use The Ratchet

1. Before assembling the furniture, please adjust the lock tool as needed.




2. Tighten or loosen the bolts


- **Tighten bolts**: Locate the turncap (picture) and rotate it clockwise to screw the bolt quickly, until it cannot be rotated any more. Then start rotating with the handle clockwise to finalize tightening the bolts.
- **Loosen bolts**: Rotate the handle counterclockwise to loosen the bolt. Then, to completely remove the bolts, continue rotating with the turncap in the same direction.




COASTER

ASSEMBLY INSTRUCTIONS







ITEM: 460332BLK (B1&B2) **ASSEMBLY INSTRUCTIONS** STEP 3 D D M M **PAGE 9 OF 22** COASTERFURNITURE.COM



ITEM: 460332BLK ASSEMBLY INSTRUCTIONS STEP 5









ASSEMBLY INSTRUCTIONS






COASTER

ASSEMBLY INSTRUCTIONS




COASTER

ASSEMBLY INSTRUCTIONS




COASTER

ASSEMBLY INSTRUCTIONS




ITEM: 460332BLK (B1&B2) **ASSEMBLY INSTRUCTIONS STEP 11**




COASTER

ASSEMBLY INSTRUCTIONS







COASTER

ASSEMBLY INSTRUCTIONS STEP 13











SIZE OF MATTRESS

The length and width of the bunk mattress are as follow:

Upper bunk	Length	Width	Thickness
Оррег Билк	74"-75"	37½" - 38½"	6" Maximum

Ensure thickness of mattress does not exceed 6" and there must be at least 5" from mattress sleeping surface to top edge of guardrail.



SAFETY WARNING



- 1. Follow the information on the warnings appearing on the upper bunk end structure and on the carton. Do not remove the warning label from bed.
- 2. Always use the recommended size mattress or mattress support or both to help prevent the likelihood of entrapment or falls.
- 3. Surface of mattress must be at least 5 in. (127 mm) below the upper edge of guardrails.
- 4. Do not allow children under 6 years of age to use the upper bunk.
- 5. Prohibit more than one person on upper bunk.
- 6. Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.
- 7. Do not allow horseplay on or under the bed and prohibit jumping on the bed.
- 8. Always use the ladder for entering and leaving the upper bunk.
- 9. Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.
- 10. Use of a night light may provide added safety precaution for a child using upper bunk.
- 11. Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.
- 12. The use of water or sleep flotation mattress is prohibited.
- 13. Keep these instructions for future reference.

STRANGULATION HAZARD:

14. Never attach or hang items to any part of the bunk bed that are not designed for use with the bed for example, but not limited to hooks, belts, and jump ropes.


REPLACEMENT PARTS:

Replacement parts, including additional guardrails may be obtained from any COASTER Furniture Dealer.



How to Dismantle Bed Slats.

- 1. Push down the Clip of Slat Plastic Housing using Allen Key, simultaneously lift up the Slat at most.
- 2. Proceed the same procedure for another end of Slat Plastic Housing and Slat, then pull out the Slat gently.



ASSEMBLY INSTRUCTIONS






- 1. When using beds as bunk beds, the ladder MUST be securely attached to the upper bunk rail at all times.
- 2. When using the beds as two (2) separate floor-standing beds, the ladder MUST be stored in a separate location where children cannot use the ladder in any manner.
- 3. DO NOT use, nor permit children to use, the ladder in any manner whatsoever, other than to access the top unit when used as bunk beds, and only if the ladder is securely attached to the top bunk rail, as set forth in the instructions.
- 4. Any misuse or unauthorized use of the ladder could result in serious or fatal injury.
- 5. Failure to follow the above <u>WARNING</u>, and/or failure to follow assembly instructions completely, will void any and all liability of COASTER COMPANY OF AMERICA for damages and injury to persons and property.



Coasterfurniture.com | 877-COASTER (262-7837)



Inner Size: 74.50"W X 39.00"D



Note: Dimension tolerance ±5%