



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

106622
Side Chair

ITEM: **106622**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A BACK FRAME



1PC

B SEAT CUSHION
WITH FRAME



1PC

C FRONT LEG



2PCS

HARDWARE IDENTIFICATION

1 LONG BOLT
(Ø1/4" x 3" - RBW)



4PCS

2 MEDIUM BOLT
(Ø1/4" x 2-3/8" - RBW)



4PCS

3 SHORT BOLT
(Ø1/4" x 1-3/8" - RBW)



1PC

4 LOCK WASHER
(Ø5/16" - RBW)




9PCS

5 FLAT WASHER
(Ø5/16" - RBW)



9PCS

6 ALLEN WRENCH
(M4 x 59mm - RBW)



1PC

NOTE:


Quantities shown are for one chair.

ITEM: **106622**


ASSEMBLY INSTRUCTIONS





STEP 1




STEP 2



STEP 3
COMPLETE



ITEM: 106622



Note: Dimension tolerance $\pm 5\%$