













ASSEMBLY INSTRUCTIONS


42" ROUND DINING TABLE

A Table Top  1 pc	B Pedestal  1 pc	C Mounting Plate  1 pc	D Leg With Leveler  4 pcs
E Bolt $\varnothing 5/16"$ x 1-9/16"  4 pcs	F Bolt $\varnothing 1/4"$ x 1-9/16"  6 pcs	G Lock Washer $\varnothing 5/16"$ x 9/16"  18 pcs	H Flat Washer $\varnothing 5/16"$ x 3/4"  18 pcs
I Hex Nut $\varnothing 5/16"$ x 1/2"  8 pcs	J Allen Key $3/19"$  1 pc	K Wrench $1/2"$  1 pc	




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

- 1** Attach the Mounting Plate (C) to the Pedestal (B) using Bolt (E), Lock Washer (G) and Flat Washer (H) with the Allen Key (J). Do not over tighten the bolts.




- 2** Attach the Mounting Plate (C) to the Table Top (A) using Bolt (F), Lock Washer (G) and Flat Washer (H) with the Allen Key (J). Do not over tighten the bolts.




3

Attach the Leg With Leveler (D) to the Pedestal (B) using Flat Washer (H), Lock Washer (G) and Hex Nut (I) with the Wrench (K). Do not over tighten the nuts.

**4**

Stand the table up on an even surface and check for balance. If the table wobbles slightly, adjust the levelers.














Cleaning & Care :

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

ASSEMBLY INSTRUCTIONS


SLAT BACK SIDE CHAIR

A Chair Back  1 pc	B Seat Cushion  1 pc	C Front Leg  2 pcs	D Bolt $\varnothing 1/4"$ x 3"  4 pcs
E Bolt $\varnothing 1/4"$ x 1-9/16"  3 pcs	F Lock Washer $\varnothing 5/16"$ x 9/16"  11 pcs	G Flat Washer $\varnothing 5/16"$ x 3/4"  11 pcs	H Hex Nut $\varnothing 5/16"$ x 1/2"  4 pcs
I Allen Key $3/19"$  1 pc	J Wrench $1/2"$  1 pc		



This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


- 1** Attach the Front Leg (C) to the Seat Cushion (B) using Flat Washer (G), Lock Washer (F) and Hex Nut (H) with the Wrench (J).



Take the Allen Wrench and turn the bolts until the legs are secured.
DO NOT TIGHTEN THE BOLTS COMPLETELY.
Stop when you feel you are adding force to tighten the bolts.

- 2** Attach the Seat Cushion (B) to the Chair Back (A) using Bolt (D), Lock Washer (F) and Flat Washer (G) at the corners. Use Bolt (E), Lock Washer (F) and Flat Washer (G) for the middle holes of the back rail. Secure both parts with the Allen Key (I).

Stand the chair on an even surface and check for balance. If the chair wobbles slightly, apply downward pressure on the uneven leg and tighten the bolts to correct the imbalance. Once the chair is balanced, apply downward pressure evenly in the center of the chair and tighten all bolts, being careful not to over-tighten beyond the hole depth.



Helpful Tip:
While tightening the bolts from underneath, have someone sit in the chair.

Cleaning & Care :

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.