



Liberty Furniture
INDUSTRIES, INC.

ITEM # : 303G/W-EL74B/74T,ER74B/74T,LB00,TV72

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all **6** parts and compare with the parts list below :

303G/W-EL74B/74T,ER74B/74T,LB00,TV72 : Component List		
NO	Descriptions	Qty
1	Left Pier Top/Right Pier Top	2
2	Left Pier Base	1
3	Right Pier Base	1
4	Bridge	1
5	72 Ent. TV Stand	1

LIBERTY FURNITURE


ASSEMBLY INSTRUCTION

DESCRIPTION : LEFT SIDE PIER, RIGHT SIDE PIER, BRIDGE, TV STAND


6. Assembly Hardware Pack

NO	Descriptions	Qty
A	Metal Connector	8
B	CSKCB Screw M4 x 20 mm	24
C	Anti Tip Kits	5



Step 2 :



Step 1 :



Step 3 :



Assembly Completed !!

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast and easy assembly.

⚠ WARNING !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.