


CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spill immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly this item.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.


Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Seat Frame		1x
B	Leg Frame (Left)		1x
C	Leg Frame (Right)		1x
D	Center Stretcher		1x
HW 1	Jcbc Bolt M6x0.5x50mm		2x
HW 2	Barrel Nut		2x
HW 3	JcbcW Bolt M7x3.0x40mm		6x
HW 4	Allen key		1x
HW 5	Wood Button		2x



Item Id : DCH1403

Product Dimensions : 20.47" W x 17.32" D x 36.42" H




Weight Capacity : 236 lbs

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package content list.


If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time : 15 minutes.




Step 1

Screw both left and right leg with the center stretcher.



Step 2

Assembled leg to the seat frame. Follow sticker marking attach for the correct position.



Step 3

Attach wood button to cover the screw hole.