



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

723488
Coffee Table

ITEM: 723488

COASTER
FINE FURNITURE

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES


PARTS IDENTIFICATION

A TOP



1PC

B SHELF



1PC

C LEG



4PCS

HARDWARE IDENTIFICATION


1	BOLT (5/16 x 50mm - BLK)		12PCS
2	LOCK WASHER (1.6 x 14mm - BLK)		12PCS
3	FLAT WASHER (2 x 19mm - BLK)		12PCS
4	ALLEN WRENCH (M5 x 65mm - BLK)		1PC

ITEM: 723488


ASSEMBLY INSTRUCTIONS

COASTER
FINE FURNITURE

STEP 1



STEP 2



ITEM: 723488


COASTER
FINE FURNITURE

ASSEMBLY INSTRUCTIONS

STEP 3


ATTENTION !

Do not fully tighten bolts in this step.



STEP 4

Please tighten bolts 100% after assembly is complete.




ITEM: 723488



ASSEMBLY INSTRUCTIONS

STEP 5

COASTER
FINE FURNITURE




STEP 6 COMPLETE



ITEM: 723488

COASTER
FINE FURNITURE



Note: Dimension tolerance $\pm 5\%$