

Assembly Instruction

ITEM NO: 194S9720GRY/DGY-4





Ottoman




Legs and hardware are stored in the bottom of the ottoman, please take them out for assembly.

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.


Component list

No	Drawing	Qty	Description
A		1	OTTOMAN
B		4	WOODEN LEGS 177*177*45MM
C		8	BOLTS 1/4*-20*45MM
D		1	ALLEN KEY 5/ 32mm


Step 1



Step 2



Completed



Care Instruction for Textured Fabric Furniture:

In order to maintain the original appearance of your textured fabric furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and/or exposure to heating and air conditioning outlets will fade/damage fabrics. Do not place your upholstered furniture too close to windows, radiators, or vents, and be sure to use windows treatments to block the sun's rays.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connections are tight. Re-tighten if necessary.



For items use on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.