

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

701972
TV CONSOLE

ITEM:701972

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



















ASSEMBLY TIME

60 MINUTES

MAX TV SIZE : 65"

PARTS IDENTIFICATION


A	LEFT SIDE PANEL		1 PC	I	LOWER BACK PANEL		1 PC
B	RIGHT SIDE PANEL		1 PC	J	LEFT DRAWER FRONT PANEL		1 PC
C	UPPER DIVIDER PANEL		2 PCS	K	DRAWER BACK PANEL		2 PCS
D	LOWER DIVIDER PANEL		1 PC	L	LEFT DRAWER SIDE PANEL		2 PCS
E	BOTTOM PANEL		1 PC	M	RIGHT DRAWER SIDE PANEL		2 PCS
F	CROSS PANEL		1 PC	N	DRAWER BOTTOM PANEL		2 PCS
G	TOP PANEL		1 PC	O	RIGHT DRAWER FRONT PANEL		1 PC
H	UPPER BACK PANEL		1 PC	P	DRAWER SUPPORT		2 PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:701972


Q CROSS BAR



2 PCS

R
















FOOT



2 PCS

Z

HARDWARE IDENTIFICATION

NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	9	SHORT SCREW Ø 3x10mm SR		24 PCS
2	WOODEN DOWEL Ø 8x30mm		32 PCS	10	HANDLE L = 120mm		2 PCS
3	CAM BOLT Ø 7x35.5mm SR		20 PCS	11	HANDLE BOLT Ø 4x25mm RBW		4 PCS
4	CAM LOCK Ø 15x12mm SR		20 PCS	12	RUBBER Ø 52mm		3 PCS
5	LONG BOLT Ø 9.5x55mm SR		6 PCS	13	BOLT M6 x 42.5mm SR		8 PCS
6	BOLT Ø 4.5x42mm SR FOR BOTTOM PANEL		4 PCS	14	ALLEN WRENCH		1 PC
7	LONG SCREW Ø 4.3x35mm SR		14 PCS	15	STICKER Ø 20mm		4 PCS
8	RAIL L = 350mm WHT		2 SET				







Z8,Z10,Z12 not included in blister packaging.

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

STEP 1

FINE FURNITURE





Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM: 701972

STEP 2




COASTER
FINE FURNITURE




ITEM: 701972

STEP 3

COASTER
FINE FURNITURE




STEP 4




ITEM: 701972

STEP 5






STEP 6





ITEM: 701972

STEP 7

COASTER
FINE FURNITURE



STEP 8




Apply glue on all wooden dowels to ensure integrity of the structure.


ITEM: **701972**

STEP 9

COASTER
FINE FURNITURE





STEP 10




ITEM: 701972

STEP 11

COASTER
FINE FURNITURE




STEP 12




Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM: **701972**

STEP 13




STEP 14





STEP 15

COMPLETE



ITEM: 701972

COASTER
FINE FURNITURE



Note : Dimension tolerance $\pm 5\%$