

Instructions

With DripCrimp™ and less than one minute per line, you can permanently attach the emitter to the drip line for worry free operation.

The crimped copper ring locks the emitter onto the drip line while shielding it from corrosive elements.

- 1 Start with new line or cut the damaged end of an existing line.**
- 2 Slide a copper ring over the line.**
- 3 Insert the emitter into the line.**
- 4 Slide copper ring over bulge.**
- 5 Crimp the copper ring over the bulge with the DripCrimp™ crimp tool.**

Quick Tip

To open the DripCrimp™ crimp tool, simply squeeze the handles until you hear a “click”. This will open the tool allowing you to crimp the next copper ring.

