


Assembly Instructions

Caution: You should read this carefully before you proceed







Barstool



Part List


Label	Picture	Description	QTY
A	A line drawing of the backrest of the barstool, showing the woven mesh pattern and the legs.	Backrest (with Legs)	1
B	A line drawing of the left armrest of the barstool, showing the curved shape and the leg.	Left Armrest (with Leg)	1
C	A line drawing of the right armrest of the barstool, showing the curved shape and the leg.	Right Armrest (with Leg)	1
D	A line drawing of the footrest of the barstool, showing the rectangular frame.	Foot Rest	1
E	A line drawing of the seat panel of the barstool, showing the rectangular shape.	Seat Panel	1

Hardware

Label	Picture	Description	QTY
①		Bolt (M6*15mm)	9
②		Bolt (M6*35mm)	7
③		Bolt (M6*60mm)	3
④		Washer	19
⑤		Cap	11
⑥		Allen Wrench	1

Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview




This barstool has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the barstool parts, the above picture is provided to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




Unpack and place all parts on a clean, non-marring surface.

Step 2



Place the Backrest(A) on the clean, non-marring surface.
Using the Allen Wrench(6), attach the Seat Panel(E) to the Backrest(A), with Bolts(2) and Washers(4) as shown above.
Do not fully tighten the Bolts.

Step 3




Place the Right Armrest(C) on the clean, non-marring surface.

Using the Allen Wrench(6), attach the Seat Panel(E) to the Right Armrest(C) with Bolts(2) and Washers(4) as shown above.

Do not fully tighten the Bolts.

Step 4




Turn it over laying the Seat Panel(E) and the Backrest(A) on the clean, non-marring surface, with the Right Armrest(C) facing upwards.

Again, using the Allen Wrench(6), attach the Right Armrest(C) to the Backrest(A) with Bolts(3) and Washers(4), as shown above.

Do not fully tighten the Bolts.

Step 5




Please note that the upper and lower parts of the Foot rest (D) are different and the top is a little narrower than the bottom. Turn the stool on its back by placing the Backrest(A) on the clean, non-marring surface.

Attach the Foot Rest(D) to the Backrest(A) and the Right armrest(C) with Bolts(1) and Washers(4), using the Allen Wrench(6) as shown above.

Do not fully tighten the Bolts.

Step 6




Place the Left Armrest(B) on the clean, non-marring surface, and set the stool over of it, again with the Right armrest(C) facing upwards.

Attach the Left Armrest(B) to the Seat Panel(E) with Bolts(2) and Washers(4), using the Allen wrench (6) as shown above.

Do not fully tighten the Bolts.

Step 7




Place the Right Armrest(C) on the clean, non-marring surface.

Again, using the Allen Wrench(6), attach the Left Armrest(B) to the Backrest(A) with Bolts(3) and Washers(4), as shown above.

Do not fully tighten the Bolts.

Step 8




Place the Right Armrest(C) on the clean, non-marring surface.

Attach the Foot Rest(D) to the Backrest(A) and the Left armrest(B) with Bolts(1) and Washers(4), using the Allen Wrench(6) as shown above.

Tighten all the assembly screws and finish the assembly.

Step 9



Place the Barstool on a **LEVEL SURFACE** to see if it wobbles.

If it wobbles, lift the Barstool some 30cm to 50cm from the ground.

Keep your feet and toes well away from the drop zone.

Drop the Barstool freely and vertically with the four legs hitting the ground at the same time.

This Drop Test will help to ensure that all the Bolts and gaps all reach full alignment status.

Test again for evenness on a **LEVEL SURFACE**.

If no wobbles are found, proceed to tighten all the Bolts.


When tightening the Bolts, tighten sequentially.

DO NOT tighten any Bolt fully and then move on to the next one.

This may cause the frame to warp.


If there are still wobbles, loosen the Bolts and execute the same drop test, then proceed to tighten the bolts again in a sequential manner.

Step10



Cover the Bolts with Caps (5)












Step11



Your Barstool is ready for use.

This Barstool should only be used on a flat, level surface.

Care & Maintenance

- ⊘  • Prolonged exposure to rain may cause rusting which can stain floors.
 - ⊘  • Do not put hot items directly on furniture surface.
 - ⊘  • Do not clean furniture with harsh cleansers or polish.
 - ✓  • To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
 - ⊘  • Children should not climb or jump on the furniture.
 - ⊘  • Do not write on furniture without a padded barrier to protect the surface.
 - ✓  • To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
 - ⊘  • Not for commercial use. For residential use only.
 - ⊘  • Stains may be removed with mild soap solution and damp cloth.
 - ✓  • Keep away from sources of ignition.
-
- ✓  • Dust and pick-up spills using a clean, non-colored, lint-free cloth.