


ASSEMBLY INSTRUCTIONS

ANA BUFFET

ITEM#67313OAK

| | | | | |
|--------------------------|------------------------|---|---------------------------------|---|
| ASSEMBLY REQUIREMENTS | 2 – Person Assembly | 2.5Hour Assembly Time (Approximate) | Tool Required (Not Provided) |  |
|--------------------------|------------------------|---|---------------------------------|---|

Thank you for purchasing our product!

Please refer and use this assembly instruction to assemble the product.
Contact our customer service department in case there are any missing or damage parts or hardware.
Replacement parts are normally shipped within 2 or 3days.

Email : Replacements@buylateral.com
Within 30days from delivery date

We appreciate your business!

ASSEMBLY PREPARATION:

1. Remove all packaging materials ,staples and packing straps from the carton.
2. Refer to Part List and Hardware List and ensure parts and hardware are correct before assembly.
Contact customer service for missing parts.
3. Place all wooden parts on clean, flat and soft surface (e.g .carpet or rug) to prevent scratch and damage to parts.

SAFETY PRECAUTION:

1. Keep ALL HARDWARE PART OUT OF REACH OF CHILDREN.
2. DISPOSE PLASTIC PACKAGING MATERIAL IMMEDIATELY TO AVOID ANY RISK OF SUFFOCATION TO CHILDREN AND ANIMALS

TIPS FOR ASSEMBLY:

1. Allow ample room for assembly and in close proximity to where product will be placed.
2. Assemble the product on a surface that does not scratch or damage the exterior gloss and finish of the furniture.
3. Identify all the parts, hardware and quantities required for each step.
4. During assembly, do not over-tighten any fittings as this may cause damage.
5. DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.
6. Always place the product on a flat, level surface.
7. Do not sit or stand on the partially assembled product ;only use the product for which it is intended.


CARE AND MAINTENANCE:

- Use a slightly damp cloth to clean the product. Do not use bleach or abrasive cleaning material.
- Check all the fittings periodically and re-tighten as necessary. Do not use the product if any of the parts is damaged or broken.
- Never allow any kind of liquids to remain on your furniture. Absorption can cause wood to warp or delaminate.
- Do not place hot items (e.g hot drinks)directly onto the wood surface.
- Do not drag and pull your furniture.


This product is for indoor and household use only -not for commercial or industrial use.




PARTS LIST




NAME: TOP PANEL
CODE: 1
QTY: 1Pc




NAME: SIDE PANEL(LEFT)
CODE: 2
QTY: 1Pc




NAME: SIDE PANEL(RIGHT)
CODE: 3
QTY: 1Pc




NAME: BOTTOM PANEL
CODE: 4
QTY: 1Pc




NAME: PARTITION(LEFT)
CODE: 5
QTY: 1Pc




NAME: PARTITION(RIGHT)
CODE: 6
QTY: 1Pc




NAME: SMALL PARTITION
CODE: 7
QTY: 1Pc




NAME: DOOR
CODE: 8
QTY: 2Pcs




NAME: SHELVING
CODE: 9
QTY: 2Pcs




NAME: TOP BAR
CODE: 10
QTY: 1Pc




NAME: FRONT CENTER BAR
CODE: 11
QTY: 1Pc



NAME: BACK CENTER BAR
CODE: 12
QTY: 1Pc




NAME: BOTTOM BAR
CODE: 13
QTY: 1Pc




NAME: BACK PLYWOOD
CODE: 14
QTY: 1Pc




NAME: LEG
CODE: 15
QTY: 5Pcs




NAME: SMALL DRAWER FRONT
CODE: 101
QTY: 1Pc




NAME: SMALL DRAWER SIDE(LEFT)
CODE: 102
QTY: 1Pc




NAME: SMALL DRAWER BACK
CODE: 103
QTY: 1Pc




NAME: SMALL DRAWER BASE
CODE: 104
QTY: 1Pc




NAME: SMALL DRAWER SIDE(RIGHT)
CODE: 105
QTY: 1Pc




NAME: MEDIUM DRAWER FRONT
CODE: 106
QTY: 2Pcs




NAME: MEDIUM DRAWER SIDE(LEFT)
CODE: 107
QTY: 2Pcs




NAME: MEDIUM DRAWER BACK
CODE: 108
QTY: 2Pcs




NAME: MEDIUM DRAWER BASE
CODE: 109
QTY: 2Pcs




NAME: MEDIUM DRAWER SIDE(RIGHT)
CODE: 110
QTY: 2Pcs




NAME: BIG DRAWER FRONT
CODE: 111
QTY: 2Pcs




NAME: BIG DRAWER SIDE(LEFT)
CODE: 112
QTY: 2Pcs



NAME: BIG DRAWER BACK
CODE: 113
QTY: 2Pcs



NAME: BIG DRAWER BASE
CODE: 114
QTY: 2Pcs



NAME: BIG DRAWER SIDE(RIGHT)
CODE: 115
QTY: 2Pcs


HARDWARE LIST




NAME: CHIPBOARD SCREW M4X16mm
CODE: A
QTY: 84Pcs



NAME: CHIPBOARD SCREW M4X38mm
CODE: B
QTY: 12Pcs




NAME: WOOD DOWEL M8X35mm
CODE: C
QTY: 28Pcs




NAME: CAM LOCK & CAM BOLT
CODE: D
QTY: 52Sets




NAME: WOOD DOWEL M6X30mm
CODE: E
QTY: 44Pcs




NAME: EXTENSION RUNNER 400mm
CODE: F
QTY: 5Sets



NAME: CAM LOCK COVER
CODE: G
QTY: 52Pcs



NAME: HINGES H-7
CODE: H
QTY: 4Pcs




NAME: SHELVING SUPPORT
CODE: I
QTY: 8Pcs




NAME: PANHEAD CHIPBOARD SCREW M4X16mm(BLACK)
CODE: J
QTY: 26Pcs




NAME: CHIPBOARD SCREW M3X12mm
CODE: K
QTY: 8Pcs



NAME: PANHEAD SCREW M4X22mm
CODE: L
QTY: 18Pcs



NAME: HANDLE
CODE: M
QTY: 9Pcs



NAME: MAGNET & METAL WARE
CODE: N
QTY: 4Sets



NAME: CHIPBOARD SCREW M4X25mm
CODE: W
QTY: 4Pcs



NAME: FLAT WASHER M4
CODE: X
QTY: 2Pcs




NAME: SCREW PLUG
CODE: Y
QTY: 2Pcs



NAME: SAFETY BELT (150mm)
CODE: Z
QTY: 2Pcs

STEP 1


- A) Insert & secure Cam Bolt(D) to Top Panel(1)
- B) Attach Magnet(N) to Top Panel(1) secure using Chipboard Screw(A)



STEP 2

- A) Insert Wood Dowel(C) to Left,Right Side Panel(2,3)
- B) Attach Cam Lock(D) to Left,Right Side Panel(2,3)


Note : Make sure arrows on each Cam Lock points towards nearest edge with holes



STEP 3

- A) Insert Wood Dowel(C) to Left,Right Partition(5,6)
- B) Attach Cam Lock(D) to Left,Right Partition(5,6)
- C) Insert & secure Cam Bolt(D) to Left,Right Partition(5,6)

Note : Make sure arrows on each Cam Lock points towards nearest edge with holes




STEP 4

- A) Attach Extension Runner(F) to Left,Right Partition(5,6) using Chipboard Screw(A) to secure


NOTE : Chipboard Screw(A) should be assembled from the front of the runner. Start from A¹, A² then A³

NOTE : Make sure the screws are installed vertically without slant to ensure screw sits properly in the hole



STEP 5


- A) Attach Magnet(N) to Bottom Panel(4) secure using Chipboard Screw(A)



STEP 6


- A) Insert Wood Dowel(C) to Top Bar, Front Center Bar, Back Center Bar, Bottom Bar(10,11,12,13)
- B) Attach Cam Lock(D) to Top Bar, Front Center Bar, Back Center Bar & Bottom Bar(10,11,12,13)

Note: Make sure arrows on each Cam Lock points towards nearest edge with holes



STEP 7


- A) Attach Hinges(H) to Door(8) using Chipboard Screw(A) to secure
- B) Attach Magnet(N) to Door(8) secure using Chipboard Screw(K)



STEP 8

- A) Insert Wood Dowel(C) to Small Partition(7)
- B) Attach Cam Lock(D) to Small Partition(7)
- C) Insert & secure Cam Bolt(D) to Small Partition(7)

Note : Make sure arrows on each Cam Lock points towards nearest edge with holes




STEP 9

- A) Attach Extension Runner(F) to both side of Small Partition (7) using Chipboard Screw(A) to secure


NOTE : Chipboard Screw(A) should be assembled from the front of the runner. Start from A¹, A² then A³

NOTE : Make sure the screws are installed vertically without slant to ensure screw sits properly in the hole




STEP 10

- A) Insert & secure Cam Bolt(D) to Small Partition(7)




STEP 11

- A) Attach Top Bar(10) to Small Partition(7) & secure with Cam Lock(D)
- B) Using Cam Lock Cover(G) to cover Cam Lock(D)




STEP 12

- A) Attach Front Center Bar, Back Center Bar(11,12) to Small Partition(7) using Chipboard Screw(B) to secure




STEP 13

- A) Attach Bottom Bar(13) to Right Partition(6) secure with Cam Lock(D)
- B) Using Cam Lock Cover(G) to cover Cam Lock(D)




STEP 14

- A) Attach Top Bar, Front Center Bar, Back Center Bar(10,11,12) to Right Partition(6) secure with Cam Lock(D)
- B) Cover Cam Lock(D) with Cam Lock Cover(G)




STEP 15

- A) Attach Left Partition(5) to Front Center Bar , Back Center Bar, Bottom Bar(11,12,13) secure with Cam Lock(D)
- B) Cover Cam Lock(D) with Cam Lock Cover(G)




STEP 16

- A) Attach Left,Right Side Panel(2,3) and Left,Right Partition(5,6) to Bottom Panel(4) using Chipboard Screw(B) to secure




STEP 17

- A) Attach and secure Leg(15) to Bottom Panel(4) clockwise




STEP 18

- A) Attach Top Panel(1) to Left,Right Side Panel(2,3) and Left,Right Partition(5,6) secure with Cam Lock(D)
- B) Cover Cam Lock(D) with Cam Lock Cover(G)




STEP 19

- A) Attach Back Plywood(14) to assembled unit using Panhead Chipboard Screw(Black)(J) to secure




STEP 20

- A) Attach Door(8) to Left,Right Side Panel(2,3) unit secure with Chipboard Screw(A)




STEP 21

- A) Attach Handle(L) to Door(8) using Panhead Screw(M) to secure



STEP 22


- A) Insert Shelving Support(I) into Left,Right Side Panel(2,3) & Left,Right Partition(5,6) at desired shelf heights
B) Slot in Shelving(9)




STEP 23

*Following step is OPTIONAL. Follow these steps if you wish to secure unit to a wall for added safety

- i) Attach Safety Belt(Z) to Back Plywood and secure using Flat Washer(X) Chipboard Screw(W) to secure






ii) Drill a hole at the wall, insert Screw Plug(Y) into hole


iii) Move assembled unit to wall and Screw in Safety Belt(Z) using Chipboard Screw(W)

EXTENSION RUNNER ASSEMBLE STEPS:




NOTE : Align and pull/push the triggers on both sides of drawer box into the metal track on interior side of side panel

EXTENSION RUNNER SEPARATE STEPS:




HINGE ADJUSTMENT:


If the doors do not appear square or aligned, loosen or tighten the appropriate screws on each case hinge as illustrated.




1) Side to side adjustment:
Loosen Screw A, adjust gap with screw B and re-tighten Screw A





2) Depth adjustment:
Loosen Screw A, push hinge arm forwards or backwards, re-tighten screw A.



3) Height adjustment:
Loosen Screw C, adjust door height and re-tighten screw C.




- A) Attach Extension Runner(F) to Left,Right Small Drawer Side (102,105) using Chipboard Screw(A) to secure




- A) Insert Wood Dowel(E) to Left,Right Small Drawer Side(102,105) & Small Drawer Back(103)
 B) Attach Cam Lock(D) to Left,Right Small Drawer Side(102,105) & Small Drawer Back(103)
 C) Attach Cam Bolt(D) to Small Drawer Front(101) & Left,Right Small Drawer Side(102,105)

NOTE : Make sure arrows on each Cam Lock point towards nearest edge with holes




- A) Attach Left,Right Small Drawer Side(102,105) to Small Drawer Back(103) secure with Cam Lock(D)
 B) Using Cam Lock Cover(G) to cover Cam Lock(D)


NOTE : Make sure arrows on each Cam Lock point towards nearest edge with holes





- A) Slot in Small Drawer Base(104) in corresponding grooves
 B) Attach Small Drawer Front(101) to Drawer Box secure with Cam Lock(D)
 C) Using Cam Lock Cover(G) to Cover Cam Lock(D)




- A) Attach Handle(I) to Small Drawer Front(101) secure using Panhead Screw(H)



- A) Attach Extension Runner(F) to Left,Right Medium Drawer Side (107,110) using Chipboard Screw(A) to secure




- A) Insert Wood Dowel(E) to Left,Right Medium Drawer Side(107,110) & Medium Drawer Back(108)
- B) Attach Cam Lock(D) to Left,Right Medium Drawer Side(107,110) & Medium Drawer Back(108)
- C) Attach Cam Bolt(D) to Medium Drawer Front(106) & Left,Right Medium Drawer Side(107,110)




- A) Attach Left,Right Medium Drawer Side(107,11) to Medium Drawer Back(108) secure with Cam Lock(D)
- B) Using Cam Lock Cover(G) to cover Cam Lock(D)


NOTE : Make sure arrows on each Cam Lock point towards nearest edge with holes





- A) Slot in Medium Drawer Base(109) in corresponding grooves
- B) Attach Medium Drawer Front(106) to Drawer Box secure with Cam Lock(D)
- C) Using Cam Lock Cover(G) to Cover Cam Lock(D)




- A) Attach Handle(I) to Medium Drawer Front(106) secure using Panhead Screw(H)



- A) Attach Extension Runner(F) to Left,Right Big Drawer Side (112,115) using Chipboard Screw(A) to secure




- A) Insert Wood Dowel(E) to Left,Right Big Drawer Side(112,115) & Big Drawer Back(113)
- B) Attach Cam Lock(D) to Left,Right Big Drawer Side(112,115) & Big Drawer Back(113)
- C) Attach Cam Bolt(D) to Big Drawer Front(111) & Left,Right Big Drawer Side(112,115)




- A) Attach Left,Right Big Drawer Side(112,115) to Big Drawer Back(113) secure with Cam Lock(D)
- B) Using Cam Lock Cover(G) to cover Cam Lock(D)

NOTE : Make sure arrows on each Cam Lock point towards nearest edge with holes



- A) Slot in Big Drawer Base(114) in corresponding grooves
- B) Attach Big Drawer Front(111) to Drawer Box secure with Cam Lock(D)
- C) Using Cam Lock Cover(G) to Cover Cam Lock(D)



- A) Attach Handle(M) to Big Drawer Front(111) secure using Panhead Screw(L)