



# ASSEMBLY INSTRUCTIONS

---



## TOOLS REQUIRED



**Allen Wrench**

(Included)



**Phillips  
Screwdriver**

(Not Included)



**3 - People  
Recommended**

## ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



## CHECK BEFORE STARTING

☐

### **Are you missing anything?**

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.

☐

### **Should we send any replacements?**

Are there any irregularities or flaws in the parts? We can send replacements!

☐

### **Check out our Quick Tips!**

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!


☐

### **Prep Time!**

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.



# PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



## Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



## Suitable Location

Assembling near the area of the intended location is highly recommended.





## Sufficient Space

Make sure you have enough space to move around during the assembly.



## Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.




## Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


# ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY  
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**




Position each part correctly  
and insert screws or bolts into  
their respective holes.



Turn clockwise to tighten and  
only tighten when step is  
completed or when instructed  
to do so.



Use the appropriate hand tools  
or power tools for assembly.  
Select steps, such as tightening  
screws and/or bolts, may require  
hand tools to avoid causing  
damage during assembly.



Save the instructions and store  
any supplied tools for later  
maintenance.



After two weeks, check and  
tighten any loose hardware and  
repeat again every six months  
thereafter.


**IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.**



# FULL BED




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



## PARTS


### PART LIST OF HEADBOARD

#1 1pc




Headboard

#2 1pc



Headboard Leg - (R)

#3 1pc



Headboard Leg - (L)

### PART LIST OF FOOTBOARD

#4 1pc




Footboard

#5 2pcs



Acrylic Leg

#6 11pcs




Roll Slat

#7 2pcs



Center Vertical Slat

#8 4pcs



Slat Support Leg  
285x30x30mm

### PART LIST OF SIDE RAIL

#9 2pcs



Side Rail

## HARDWARE PACK IN HEADBOARD

#A 1pc



Allen Key

#B 6pcs



JCBC - M6 x35mm

#C 6pcs



M6 Spring Washer

#D 6pcs



M6 Flat Washer


#E 1pc



AC Adaptor

## HARDWARE PACK IN FOOTBOARD

#F 1pc



Allen Key

#G 4pcs




JCBC - M6 x 60mm

#H 4pcs



M6 Spring Washer

#I 22pcs





















Screw 32mm

#J 4pcs



Adjustable Leveller

# POINT 3 CARTONS

Carton	Designation	Part		Hardware	
	Headboard (1pc)	#1		 #A x 1pc	
	Headboard Leg - (R) (1pc)	#2		 #B x 6pcs	
	Headboard Leg - (L) (1pc)	#3		 #C x 6pcs	
				 #D x 6pcs	
				 #E x 1pc	
	Footboard (1pc)	#4		 #F x 1pc	
	Bun foot (2pcs)	#5		 #G x 4pcs	
	Slat (11pcs)	#6		 #H x 4pcs	
	Center Vertical Slat (2pcs)	#7		 #I x 22pcs	
	Slat Support Leg (4pcs)	#8			
	Side Rail (2pcs)	#9			

# ASSEMBLY INSTRUCTIONS

1

Part (#1) x 1pc

Part (#2) x 1pc


Part (#3) x 1pc

Hardware (#A) x 1pc

Hardware (#B) x 6pcs


Hardware (#C) x 6pcs

Hardware (#D) x 6pcs



2

Hardware (#E) x 1pc



# ASSEMBLY INSTRUCTIONS

## 3

Part **#4** x 1pc

Part **#5** x 2pcs


Attach legs (#5) to the footboard (#4).

Bun Foot cover




Remove Acrylic Leg cover before assemble.

**#5**




**#5**



## 4

Part **#1** x 1pc

Part **#9** x 2pcs





# ASSEMBLY INSTRUCTIONS

5



- Part (#6) x 11pcs    Hardware (#F) x 1pc  
 Part (#7) x 2pcs    Hardware (#G) x 4pcs  
 Part (#8) x 4pcs    Hardware (#H) x 4pcs  
                             Hardware (#I) x 22pcs  
                             Hardware (#J) x 4pcs

Align center slat (#7) to the side rails then secure by using bolts (#F) with washers (#H).



Align center slat (#7) to side rails (#6), then secure by using bolts (#G) with washers (#H) onto support legs (#8). Attach and adjust adjustable leveler (#J) to support legs (#8).

6



## ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



### Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



### Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.