

TOOLS REQUIRED



Allen Wrench

(Included)



Phillips Screwdriver

(Not Included)



2 - People Recommended

ASSEMBLY RATING



EASY DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION # 20-01-03



Are you missing anything?	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed on Page 6 are accounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

CAM LOCK FASTENER ASSEMBLY INSTRUCTIONS

Note:


Every cam lock bolt must have a cam lock connector in order to fasten the parts together.




cam bolt cam lock




screwdriver




Screw the cam bolt into panel.



Insert the cam bolt into the bolt hole of joint panel.



Align the cam lock with its side opening (or arrow) pointing to cam bolt.





Turn the cam lock clockwise gently until it will not turn any more.


BAR TABLE



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.







HARDWARE









SHORT SCREW 4 x 12mm

LONG SCREW 4 x 38mm

ACCESSORIES









1

Part #1 x1pc

Part #2 x1pc


Part #5 x2pcs

Part (#11) x1pc

Hardware #B x4pcs

Hardware#Jx10pcs

Align bottom crossbars (#5) and top panel (#11) to the frames (#1,2), then secure by using bolts (#J). Attach caps (#B) to the bottom of the frame (#1,2).



2


Part #16 x1pc

Part #17 x1pc

Hardware(#I)x4pcs

Hardware (#N) x2pcs


Secure bottom panel (#16) to the crossbars by using bolts (#I). Align small middle panel (#17) to the bottom panel (#16), then secure by using screws (#N).



3

Part #13 x1pc
Part #17 x1pc
Hardware #G x2pcs
Hardware #F x2pcs
Hardware #K x4pcs


Secure cam bolts (#I) onto large middle panel (#13), then align the large middle panel (#13) to small middle panel (#17). Secure middle panels (#13,17) by using cam locks (#G). Secure middle panel (#13) to frames by using screws (#K).



4


Part #14 x1pc
Part #15 x1pc
Hardware #M x8pcs

Align side panels (#14,15) to the frames, then secure by using screws (#M).






Align glass holders (#9) to top panel, then secure by using screws (#M).








Align front panel (#12) to the frame, then secure by using bolts (#J).



7
Part #8 x2pcs
Hardware #M x8pcs

Align bottle racks (#8) to the unit, then secure by using screws (#M).



8


Part (#3) x2pcs
Part (#4) x2pcs
Hardware (#1) x2pcs
Hardware (#3) x4pcs

Hardware#K) x4pcs

Align support crossbars (#4) to the decoration frame (#3), then secure by using bolts (#J). Align decoration frame (#3) to the unit, then secure by using screws (#K).

9

Part #10 x1pc
Hardware #A x4pcs
Hardware #D x4pcs
Hardware #H x4pcs



10

Part #6 x2pcs


Part #7 x1pc

Hardware#B) x2pcs

Hardware(#C) x2pcs


Hardware(#J) x8pcs

Hardware(#L) x2pcs




11

Part #18 x1pc
Hardware #E x4pcs



12



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.