















CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.
The use of steam or water-based cleaners may cause excessive shrinking or staining.

NOTICE


- * Please make sure that you have all parts indicated before you begin assembly of this item.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	TOP PANEL		1X
B	LEFT PANEL		1X
C	RIGHT PANEL		1X
D	DIVIDER		1X
E	BOTTOM ASSEMBLY		1X
F	BACK PANEL		1X
G	LEG FRAME		2X
H	CENTER LEG		2X
I	BASE FRAME		1X
J	DRAWER FRONT		2X
K	DRAWER LEFT		2X
L	DRAWER RIGHT		2X
M	DRAWER BACK		2X
N	DRAWER BASE		2X

















Model# CNS5002A
Product Dimensions: 42"W x 15"D x 31"H





WEIGHT CAPACITY :
TOP : 110 LBS
DRAWER : 30 LBS

WARNING: DO NOT OVER TORQUE
BOLTS/SCREWS

PIECE	DESCRIPTION	PICTURE	QUANTITY
1	30 MM BOLT	M6x30mm 	10X
2	15 MM BOLT	M6x15mm 	2X
3	SPRING WASHER		4X
4	FLAT WASHER		6X
5	1 1/4" FLAT HEAD SCREW	M3x32mm 	16X
6	3/4" FLAT HEAD SCREW	M3x19mm 	8X
7	5/8" FLAT HEAD SCREW	M3x16mm 	10X
8	CAMBOLT		18X
9	CAMLOCK		18X
10	MACHINE SCREW	M4x25mm 	4X
11	HANDLE		2X
12	WOODEN DOWEL		12X
13	WEDGE		10X
14	ALLEN KEY		1X


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver


	
<p>STEP 1 ATTACH CAMBOLTS TO TOP PANEL AND BOTTOM ASSEMBLY.</p>	<p>STEP 2 ATTACH LEFT AND RIGHT PANELS AND DIVIDER TO TOP PANEL USING CAMLOCKS AND WOODEN DOWELS.</p>

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver





STEP 3 SLIDE BACK PANEL INTO THE GROOVE OF UNIT.



STEP 4 ATTACH BOTTOM ASSEMBLY TO UNIT USING CAMLOCKS AND WOODEN DOWELS.



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver

	
<p>STEP 5 ATTACH LEG FRAMES AND CENTER LEGS TO UNIT USING 30 MM BOLTS, 15 MM BOLTS, SPRING WASHERS AND FLAT WASHERS. TURN BOLTS USING ALLEN KEY. NOTE : DO NOT OVER TIGHTEN THE BOLTS.</p>	<p>STEP 6 ATTACH BOTTOM LEG TO UNIT USING 30 MM BOLTS. TIGHTEN BOLTS USING ALLEN KEY. NOTE : TIGHTEN ALL BOLTS COMPLETELY USING ALLEN KEY FROM STEP 5.</p>



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver

	
<p>STEP 7 ATTACH WEDGES TO UNIT USING 5/8" FLAT HEAD SCREWS. ADJUST THE ADJUSTER THAT HAS ALREADY BEEN ASSEMBLED TO THE LEGS TO STABILIZE YOUR UNIT.</p>	<p>STEP 8 ATTACH HANDLE TO DRAWER FRONT USING MACHINE SCREWS. ATTACH DRAWER LEFT AND RIGHT TO DRAWER BACK USING 1 1/4" FLAT HEAD SCREWS. SLIDE DRAWER BASE INTO THE GROOVE. ATTACH DRAWER FRONT TO DRAWER LEFT AND RIGHT USING 1 1/4" FLAT HEAD SCREWS.</p>



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver



STEP 9 LOOSEN SLIGHTLY THE SCREWS PRE-INSTALLED ON THE BACK OF THE DRAWER FRONTS.

STEP 10 INSERT THE DRAWER INTO THE UNIT, THEN ADJUST THE DRAWER FRONT PANEL LEFT OR RIGHT AND UP OR DOWN UNTIL THE DRAWER GAPS LOOK PROPORTIONAL.



STEP 11 PULL THE DRAWER OPEN SLOWLY AND RE-TIGHTEN THE SCREWS FROM STEP 9. MAKE SURE THE FRONT PANEL DOES NOT MOVE AND LOCK THE DRAWER FRONT PANEL INTO POSITION WITH 3/4" FLAT HEAD SCREWS.

STEP 12 SLIDE THE DRAWERS INTO UNIT.