
Assembly Instructions

Caution: You must read this before you proceed

Recliner Chair



| Parts List | | | |
|-----------------|---------|-----------------|-----|
| Label | Picture | Description | QTY |
| А | | Chair Backrest | 1 |
| В | | Chair Base Body | 1 |
| С | | Front Leg | 2 |
| D | | Back Leg | 2 |
| <u>Hardware</u> | | | |
| Label | Picture | Description | QTY |
| 1) | ** | Plastic Washer | 7 |


Silicon Washer

2

2

Assembly Preparation

Before Beginning Assembly:





Read instructions, cover to cover-



Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-




Save all packaging until finished-

Assembly Steps



This Recliner Chair has multiple parts and may require up to some 30 minutes to assemble. To give you an overview of the Reclining Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions here below to familiarise yourself with the parts and steps before assembly.






Position the Chair Base Body(B) on a clean non-marring surface (Preferably on a surface that won't scratch the upholstery.)

Take the inner box from the Chair Base Body(B) then remove the Legs and Hardware from the inner box as shown.






Position the Chair Base Body(B) on its back as shown above.

Install the Front Leg(C) to the Chair Base Body(B) by placing a Plastic Washer(①) on the leg stem, then insert the leg into the front corner of the chair and turn it clockwise as shown.

Repeat the same step to install the other Front Leg(C).

Note: The use of Plastic Washers (①) are OPTIONAL and are especially useful to help alleviate slight wobbleness. Some Legs may need more than one Plastic Washer(①) whilst some Legs may not need any.

Step 3




Install the Back Leg(D) to the Chair Base Body(B) by placing a Plastic Washer(①) and a Silicon Washer(②) on the leg stem, then insert the leg into the back corner of the base and turn it clockwise as shown.

Repeat the same step to install the other Back Leg(D).


Note: The use of Plastic Washers(①) are OPTIONAL and are especially useful to help alleviate slight wobbleness. Some Legs may need more than one Plastic Washer(①) whilst some Legs may not need any.

Step 4



With assistance from your adult partner, hold up the Chair Backrest(A) and stand behind the chair. Insert the small metal arms on the sides of the Chair Backrest(A) into the prefabricated slide lock gadgets on the Chair Base Body(B) as shown above. Firmly but gently, push the Chair Backrest(A) downwards until the Backrest is fully slotted and locked into position.


Step 5



Smooth down the fabric flap on the Chair Backrest.

Run your hands down both sides of the flap, from top to bottom, allowing the magic tape to adhere to the flap under the seat of the chair.

Step 6



Your Recliner chair is ready for use.

This Recliner chair can only be used on a flat, level surface.

User Instructions.

Recliner Chair

Please read the Instruction Manual below carefully before use.

This is a Recliner Chair. At anytime in a reclined seat position or in the upright position, you may enjoy the rocking motion by using your body weight in a back-front rocking motion.

Supervise any children that may use this Recliner.



Do not let children stand in front of or behind the Recliner Chair when opening or closing the footrest. Do not put your hands inside the Footrest when opening or closing it. Do not sit on any armrest of this Recliner Chair.

To get into a reclined posture - To Recline backrest


Sit into the seat.

Place your feet apart.

Place your left and right arm onto the armrest.

Synchronise a backward push with your arms.

Use your body weight and push backwards into the seat into a fully reclined position.



To get out of chair - move Seat back into Upright Position

Tilt your body weight slightly forward and upwards.

The seat back will come up to an upright position.

When necessary, use your arms to help lift - push yourself out of the seat.









Care & Maintenance



 Furniture may scratch floors. We recommend using furniture pads to protect your floors.



Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



Do not place furniture under direct sunlight.



Do not place furniture near heating or cooling vents.



 Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside . For indoor use only.



Not for commercial use. For residential use only.



 Stains may be removed with mild soap solution and damp cloth.



Children should not climb or jump on the furniture.



 Dust and pick-up spills using a clean, non-colored, lint-free cloth.