


ASSEMBLY INSTRUCTION

SKU CODE: (WF286886-WF286887-WF286888)

This set is included 3 boxes if don't receive full 3 boxes please contact our customer service team



! SAFETY WARNINGS !

1. This bed is designed for use only mattress (es) meeting the following specifications on the upper bunk, and lower bunk

Upper bed

Bed Type	Length	Width	Thickness
<i>Full Standard</i>	<i>74" - 75"</i>	<i>53 1/2"</i>	<i>6" max</i>


Lower bed

Bed Type	Length	Width	Thickness
<i>Full Standard</i>	<i>74" - 75"</i>	<i>53 1/2"</i>	<i>8" max</i>



















2. Replacement parts, including additional guardrails, maybe obtained from any of our (GIGACLOUD TECHNOLOGY (USA) INC. 18961 ARENTH AVENUE CITY OF INDUSTRY, CA, 91748) dealers
3. Follow the information on the warnings appearing on the upper bunk bed end structure and on the carton. Do not remove warning label from bed
4. Always use the recommended size mattresses or mattress supports, or both, to help prevent the likelihood of entrapment or falls.
5. Surface of mattress must be at least 5" (127mm) below the upper edge of guardrails
6. Do not allow children under 6 years of age to use the upper bunk.
7. Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.
8. Do not allow horseplay on or under the bed and prohibit jumping on the bed.
9. Always use the ladder for entering and leaving the upper bunkAlways use the ladder for entering and leaving the upper bunk.
10. Do not use substitute part. Contact the manufacture or dealer for replacement part
11. Use of a night light may provide added safety precaution for a child using the upper bunk..
12. Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.
13. The use of water or sleep flotation mattresses is prohibited
14. STRANGULATION HAZARD - Never attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hook, belts and jump ropes
15. Keep these instruction for future reference
16. Prohibit more than one person on upper bunk
17. We recommend assembling your bunk bed on the shipping carton to protect your floor or carpet
18. Be certain all staples are out of the box before beginning assembly on the shipping carton.

l:










ASSEMBLY INSTRUCTION
















Part List(WF286886)-Hardware List

A1  Bottom legs 2 pcs	A2  Bottom legs 2 pcs	A3  Upper leg 1 pc
A4  Upper leg 1 pc	A5  Upper leg 1 pc	A6  Upper leg 1 pc
B1  Bottom Side Frame(Left) 1 pc	B2  Bottom Side Frame(Right) 1 pc	B3  Top horizontal bar 2pcs
B4  Upper Side Frame(Left) 1 pc	B5  Top horizontal bar 1pcs	B6  Top horizontal bar 1pcs
B7  Upper Side Frame 1pc	D3  Support Slats 2 pcs	E5  Side panel 1pc
E11  Back Frame 1pc	E13  Side Frame 1pc	E14  Side Frame 1pc





















Part List(WF286887)

C1	 <p>Guard rail 4pcs</p>	C2	 <p>Side rails 2pcs</p>	C3	 <p>Vertical guard rails 4pcs</p>
C4	 <p>Support Slat 1pc</p>	C5	 <p>Side rails 2pcs</p>	F1	 <p>Trundle -Front Panel 1pc</p>
F2	 <p>Trundle -Back Panel 1pc</p>	F3	 <p>Trundle-Side Panel 2pcs</p>	F4	 <p>Trundle-Slats 7pcs</p>





Part List(WF286888)


<div>E1</div> <div></div> <div>Front panel 1 pc</div>	<div>E2</div> <div></div> <div>Front panels 2pcs</div>	<div>E3</div> <div></div> <div>Front panel 1pc</div>
<div>E4</div> <div></div> <div>Side panel 1pc</div>	<div>E6</div> <div></div> <div>Side panel 1pc</div>	<div>E7</div> <div></div> <div>Top panel 1pc</div>
<div>E8</div> <div></div> <div>Top panel 1pc</div>	<div>E9</div> <div></div> <div>Top panel 1pc</div>	<div>E10</div> <div></div> <div>Top panel 1pc</div>
<div>E12</div> <div></div> <div>Back Frame 1pc</div>	<div>E15</div> <div></div> <div>Support Bar 1pc</div>	<div>D1</div> <div></div> <div>Slats 26 pcs</div>
<div>D2</div> <div></div> <div>Slats 2 pcs</div>		

Hardware List

1	 Screws 1/4" x100 16pcs	2	 Ø10 x 40 mm Wood dowel 42pcs	3	 M4 x 30 mm Wood Screws 89pcs
4	 Ø1/4" x 80 mm Hex-Head bolts 24pcs	6	 Allen Key 1pc	7	 Steel Bracket 2pc
8	 M4 x 20 mm Wood Screws 16pcs	9	 Ø1/4" x 25 mm Hex-Head bolts 39pcs	10	 Ø1/4" x 15 mm Canopy head though- 14pcs
11	 Ø1/4" x 50 mm Hex-Head bolts 2pcs	12	 Ø1/4" x 13 mm Horizontal-Hole bolts 28pcs	13	 Ø12 x 110 mm Wood dowel 4pcs
14	 Ø8 x 25 mm Wood dowel 22pcs	15	 M6 x 15 mm Wood Screws 38pcs	16	 Screws 1/4" x60 4pcs
17	 Ø1/4" x 35 mm Hex-Head bolts 10pcs	18	 Screws 1/4" x50 2pcs	19	 Wood Handle 2pcs
20	 Ø1/6" x 25 mm 2pcs	21	 Ø1/4" x 30 mm Hex-Head bolts 4pcs		

Hardware List

<div>22</div> <div></div> <div>Ø8 x 30 mm Wood dowel 2pcs</div>	<div>23</div> <div></div> <div>Ø1/4" x 70 mm Hex-Head bolts 4pcs</div>	<div>24</div> <div></div> <div>Wheels 4pcs</div>
<div>25</div> <div></div> <div>Stop Trundles - 2pcs</div>		




Assembly Tools Required (Not Included)

STEP 1: Following below illustration Assembly Bottom bed's Headboard.

Using hardware #1 and dowel #2 connect A1 and A2 legs with B1 Frame.


Look at detail view for more detail



STEP 2: Following below illustration Assembly Bottom bed's Headboard.

Using hardware #3 connect Frame(completed on step 1) with B3 to complete LEFT side of Bottom Bed.


Look at detail view for more detail



STEP 3: Following below illustration Assembly Bottom bed's Footboard.

Using hardware #1 and dowel #2 connect A1 and A2 legs with B2 Frame.


Look at detail view for more detail



STEP 4: Following below illustration Assembly Bottom bed's Headboard.




Using hardware #3 connect Frame(completed on step 3) with B3 to complete RIGHT side of Bottom Bed.


Look at detail view for more detail



STEP 5: Following below illustration Using hardware #4,#12 and dowel #2


follow detail view to Assembly Bottom bed's Headboard(Completed on step 2) and Footboard(Completed on step 4) with siderail C5(x2).Look at detail view for more detail

12	4	2
		
8pcs	8pcs	4pcs




STEP 6-1: Following below illustration:

Connect 2 slats D2 with 2 Leg(center) D3 by using hardward #9.



9




2pcs

STEP 6-2: Following below illustration:

-Screw 12 slats D1 and 2 slats D2(Completed on step 6-1) with Side Rail C5 by using hardward #3.

-Screw 2 Stop Trundle on Siderail using hardward #3

-Look at detail view for more detail



3



32pcs


25





2pcs

STEP 7: Following below illustration Assembly Upper bed's Headboard.


Using hardware #1 and dowel #2 connect A3 and A4 legs with B4 Frame.
Look at detail view for more detail






1	
	4pcs
2	
	8pcs

STEP 8: Following below illustration Assembly Upper bed's Headboard.

Using hardware #3 connect Frame(completed on step 7) with B5 Woodbar
Using hardware #7 connect Frame with Bracket #8 to complete LEFT side of Upper Bed.
Look at detail view for more detail




3	
	5pcs
8	
	4pcs
7	
	1pcs

STEP 9: Following below illustration Assembly Upper bed's Footboard.

Using hardware #9,#10 connect B7 Frame with B6 Woodbar

Using hardware #7 connect Frame with Bracket #8.

Look at detail view for more detail




9	8
2pcs	4pcs
10	7
2pcs	1pcs

STEP 10: Following below illustration Assembly Upper bed's Footboard.

Using hardware #1,#11 and dowel #2 connect Frame(completed on step 9) with Legs A5,A6

Look at detail view for more detail




1
4pcs
2
2pcs
11
2pcs

STEP 11: Following below illustration Assembly Upper bed's Footboard.

Using hardware #9,#10 connect B7 Frame with B6 Woodbar

Using hardware #7 connect Frame with Bracket #8.

Look at detail view for more detail



STEP 12: Following below illustration Using hardware #4,#5,#12 and dowel #2

follow detail view to Assembly Upper bed's Headboard(Completed on step 8) and

Footboard(Completed on step 10) with Frame (Completed on step 11).

Look at detail view for more detail


STEP 13: Following below illustration:

- Put Support Slat C4(x1) on position
- Screw 14 slats D1 and with Side Rail C2 by using hardward #3.
- Look at detail view for more detail

3




28pcs




STEP 14: Following below illustration. Lay the Upper Bed (Completed on step 13)
on Bottom Bed (Completed on step 6-2). Using the Dowel #13 to connect head of Bottom Bed legs
with end of Upper Bed legs.

13




4(pcs)



STEP 15-1:ASSEMBLY STAIRCASE

Using hardware #9 and dowel #14 connect Support Bar (E15) with E1,E10 panels




9



3pcs


14



2pcs

STEP 15-2:ASSEMBLY STAIRCASE

Using hardware #9 and dowel #14 connect Frame(completed on step15-1) with E2 panel




9



2pcs


14



2pcs

STEP 15-3:ASSEMBLY STAIRCASE

Using hardware #9 and dowel #14 connect Frame(completed on step15-2) with E9 panel




9



2pcs


14



2pcs

STEP 15-4:ASSEMBLY STAIRCASE

Using hardware #9 and dowel #14 connect Frame(completed on step15-3) with E2 panel




9



2pcs


14



2pcs

STEP 15-5:ASSEMBLY STAIRCASE

Using hardware #9 and dowel #14 connect Frame(completed on step15-4) with E8 panel




9



2pcs


14



2pcs

STEP 15-6:ASSEMBLY STAIRCASE

Using hardware #9 and dowel #14 connect Frame(completed on step15-5) with E3 panel




9



2pcs


14



2pcs


STEP 15-7:ASSEMBLY STAIRCASE

Using hardware #9 and dowel #14 connect Frame(completed on step15-6)
with E12 Frame



STEP 15-8:ASSEMBLY STAIRCASE

Using hardware #9 and dowel #14 connect Frame(completed on step15-7)
with E7 Panel




STEP 15-9:ASSEMBLY STAIRCASE

Using hardware #15 connect Frame(completed on step15-8) with E4,E5,E6 Panels

15




38pcs



STEP 15-10:ASSEMBLY STAIRCASE


Using hardware #16 connect E13 Frame with E14 Frame



16



2pcs



21/26

STEP 15-11:ASSEMBLY STAIRCASE

Using hardware #17,#18 connect Frame(completed on step15-9) with Frame(completed on step15-10) and E11 Frame

17




5pcs

18



2pcs



STEP 16

Align and fix the staircase and the bunk beds, Using #16,#17 connect the staircase with bunk beds

17




5pcs



16




2pcs



STEP 17-1: Assembly Wood Handle With Front Trundle F1 Using #20





2pcs




2pcs


STEP 17-2:




4pcs



4pcs




4pcs




2pcs

STEP 17-3:



STEP 17-4:



STEP 18: CONGRARULATION. YOU HAVE COMPLETED THE BED. just one more step to push the Under Bed

Trundle into it position

