
# **User's Manual**



### **INSTALLATION INSTRUCTIONS**


# **Installation Manual**














### IAPMO RESEARCH AND TESTING, INC.













### IAPMO RESEARCH AND TESTING, INC.









# **CERTIFICATE OF LISTING**





### IAPMO RESEARCH AND TESTING, INC.














### **BEFORE INSTALLATION**

# **Precautions and Maintenance**

- 1. In order to ensure the durability of the product, please be as gentle and slow as possible during operation.
- 2. Clean the filter regularly.
- 3. When the shower is used for a long time and water is found to flow out intermittently there must be debris blocking the water outlet. At this time, you only need to gently touch & clean the soft rubber tips on the shower, then the debris will be automatically rushed out.
- 4. If any dirt on surface, clean with soft liquid or transparent glass detergent, then rinse it with soft water, finally gently wipe it with a dry soft cloth.
- 5. Do not use any scrubbing detergent, polisher, sand -cloth, paper tissue, or scraper.
- 6. Do not use acid detergent, insoluble & grain-like detergent or soap.
- 7. If you will not use the shower for a long time, please close the main water inlet valve in your home.
- 8. When the ambient temperature is under 0° C/32° F, please take necessary measures to keep the water equipment warm.



# Installation of Main Body Parts list


NO.	Description	Quantity
1	Valve Body	1
2	Faceplate	1
3	Rubber 0-ring	3
4	Handle cover	3
5	Hexagon socket screw	3
6	Decorative cap	3
7	Kits bag	1

### **INSTALL THE SHOWER VALVE BODY**

This product has been inspected and debugged by the factory to the best condition. Please do not disassemble and assemble it yourself.





Before installing the product, please be sure to remove sundries and sludge from the water pipe to prevent sundries from blocking the product.



1. Unscrew the decorative screws, counter-clockwise and pull them out, then use the Allen screw to remove the hexagon socket screws.


2. Remove the face plate, take apart the valve into 3 parts as shown in the picture.







3. With reference to the basic dimensions of the embedded body, excavate the embedded ports of the main body, hot & cold water inlet pipe and the outlet pipe.


4. Drill four 6mm positioning holes according the product size.






5. Harmer the expanded screw in the 4 drilled holes.









### **INSTALL THE SHOWER VALVE BODY**


- 7. Use a Phillips screwdriver to tighten the 4 self-tapping screws, fix the valve body on the wall.
- 8. Connect all the pipes to check leakage, confirm no leak occurs when turn on water.






9. Fix the decorative plate and knobs on the valve body. Screw the hand-wheel on the handles and tighten with a Allen wrench.










### **INSTALLATION OF THE HAND SHOWER**

- 1. Wrap the PTFE tape on the 1/2 thread of the stand for shower head.
- 2. Screw the stand for shower head clockwise on the outlet hole of the water outlet.
- 3. Connect the water outlet of the stand for shower head with the tube of shower head, and put the hand-held shower head in the stand.









### **INSTALLATION OF RAIN SHOWER HEAD**


## Sketchy diagram



1. After receiving the product, the customer should use the hexagonal key to loosen the 4 screws in the above direction.




2. Separate the showerhead part from the bracket.




### **INSTALLATION OF RAIN SHOWER HEAD**


1. Refer to the basic size of the product and cut holes at a suitable position under the ceiling.




2. With reference to the basic size of the product, drill four Ø0.39" holes at a suitable position under the ceiling.




3. Use a hammer to drive the four explosive screw heads into the drilled holes.




4. Use a socket wrench to remove the lock nut, spring washer, and flat washer counterclockwise.



5. Move the bracket upward so that the four expansion screw heads pass through the four holes of the bracket.




6. Install the washer and spring washer with explosive screw heads, and then use a copper sleeve wrench to lock the nut to the bracket, and the bracket is flush with the ceiling.





7. Connect the 1/2 elbow water inlet braided pipe and 1/2 three-way joint as shown in the figure.

8. Lock the connected 1/2 elbow water inlet braided pipe and 1/2 three-way joint on the waterfall water joint; then install the 1/2 two-way joint on the top spray panel group.

9. Connect the 1/2 water inlet braided pipe to the top spray panel group.









### **INSTALLATION OF RAIN SHOWER HEAD**


10. Connect the power plug



11. Remove the ceiling plasterboard and connect the outer thread end of the 1/2 inlet braid pipe to the water inlet hole on the ceiling.




12. Lock the shower assembly onto the bracket with a hexagonal spoon. And the power plug in the plug board after power; Put in the drywall.



### INSTALLATION OF SIDE SPRAY


1. Use a hexagonal wrench to turn counterclockwise to remove the 1/2 threaded joint.




2. Wrap the PTFE tape on the 1/2 threaded joint.




4. Rotate the side nozzle clockwise and tighten it on the 1/2 threaded joint.



3. Use a hexagonal wrench to rotate clockwise to install the 1/2 threaded joint on the wall side spray joint. (Note: The 1/2 threaded joint has an internal threaded end facing outward).



5. Install the remaining side sprinklers according to the previous steps.



### **CLEANING CARE**

In order to keep the appearance of product clean, bright and good performance, please take care of the product as follows;

- 1. Rinse with water only and dry with soff cotton cloth;
- 2.Use mild liquid and colorless glass cleaner to remove surface dirt and scale film, or use polish without abrasive effect:
- 3.Do not use abrasive deterfgent, polish, emery cloth, paper towel or scraper, etc;
- 4.Do not use acid cleaner, or cleaner and soap with insoluble gran etc;
- 5.In the process of use, mud my accumulate in the bubbler and make the water flow show, The bubbler can be unscrewed, rinsed with water, and then installed back in place.





