


















CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.
The use of steam or water-based cleaners may cause excessive shrinking or staining.

NOTICE


- * Please make sure that you have all parts indicated before you begin assembly of this item.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QTY	CARTON CALL
A	TOP PANEL		1X	1 OF 2
B	LEFT PANEL		1X	2 OF 2
C	RIGHT PANEL		1X	2 OF 2
D	FRAME ASSEMBLY		1X	2 OF 2
E	RAIL		1X	1 OF 2
F	BOTTOM PANEL		1X	1 OF 2
G	UPPER BACK PANEL		1X	1 OF 2
H	LOWER BACK PANEL		1X	1 OF 2
I	LEG FRAME		2X	1 OF 2
J	SIDE FRAME		2X	1 OF 2
K	CENTER FRAME		2X	1 OF 2
L	DRAWER FRONT		6X	1 OF 2
M	DRAWER LEFT		6X	2 OF 2
N	DRAWER RIGHT		6X	2 OF 2
O	DRAWER BACK		6X	1 OF 2
P	DRAWER BASE		6X	2 OF 2
Q	DRAWER SUPPORT		6X	2 OF 2














Model# DRS5003
Product Dimensions: 54"W x 18"D x 36"H





WEIGHT CAPACITY :
TOP : 110 LBS
DRAWER : 30 LBS

WARNING: DO NOT OVER TORQUE
BOLTS/SCREWS

PIECE	DESCRIPTION	PICTURE	QTY	CARTON CALL
1	45 MM BOLT	M6x45mm 	8X	2 OF 2
2	35 MM BOLT	M6x35mm 	8X	2 OF 2
3	20 MM BOLT	M6x20mm 	4X	2 OF 2
4	1 1/4" ROUND HEAD SCREW	M4x32mm 	1X	2 OF 2
5	1 1/4" FLAT HEAD SCREW	M3x32mm 	66X	2 OF 2
6	3/4" FLAT HEAD SCREW	M3x19mm 	18X	2 OF 2
7	CAMBOLT		34X	2 OF 2
8	CAMLOCK		34X	2 OF 2
9	DOWEL	Ø10x28mm 	6X	2 OF 2
10	DOWEL	Ø8x28mm 	8X	2 OF 2
11	ALLEN KEY		1X	2 OF 2



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver

 <p>This diagram illustrates the first step of assembly. It shows five panels: a top panel (A), a left panel (G), a right panel (H), a bottom panel (F), and an upper back panel (B). A lower back panel (C) is also shown. Each panel has several pre-drilled holes. Small vertical lines with circles at the top, labeled with the number 7, indicate the locations where cambolts should be inserted into the holes on each panel.</p>	 <p>This diagram illustrates the second step of assembly. It shows the upper back panel (B) and the lower back panel (C) being joined together. A circular inset shows a camlock (8) being rotated 180 degrees, indicated by a curved arrow and the text '180°'. Another circular inset shows two camlocks (8) with a large 'X' over the one on the left and a large checkmark over the one on the right, indicating the correct orientation for locking. The main diagram shows the panels aligned with the camlocks (8) inserted into the corresponding holes.</p>
<p>STEP 1 ATTACH CAMBOLTS TO TOP PANEL, LEFT AND RIGHT PANELS, BOTTOM PANEL AND UPPER AND LOWER BACK PANEL.</p>	<p>STEP 2 JOIN UPPER AND LOWER BACK PANELS USING CAMLOCKS.</p>



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver

	
<p>STEP 3 ATTACH LEFT PANEL TO BACK PANEL ASSEMBLY USING CAMLOCKS.</p>	<p>STEP 4 ATTACH RAIL TO UNIT USING CAMLOCKS.</p>



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver

	
<p>STEP 5 ATTACH RIGHT PANEL TO UNIT USING CAMLOCKS.</p>	<p>STEP 6 ATTACH FRAME ASSEMBLY TO UNIT USING 1 1/4" ROUND HEAD SCREW, CAMLOCKS AND Ø10x28 MM DOWELS.</p>



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver

	
<p>STEP 7 ATTACH TOP PANEL TO UNIT USING CAMLOCKS AND Ø8x28 MM DOWELS.</p>	<p>STEP 8 ATTACH BOTTOM PANEL TO UNIT USING CAMLOCKS AND Ø8x28 MM DOWELS.</p>



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver

	
<p>STEP 9 ATTACH SIDE FRAMES TO LEG FRAMES USING 45 MM BOLTS. ATTACH CENTER FRAMES TO LEG FRAMES USING 20 MM BOLTS. TIGHTEN THE BOLTS USING ALLEN KEY.</p>	<p>STEP 10 ATTACH UNIT FROM STEP 9 TO UNIT FROM STEP 8 USING 35 MM BOLTS. TIGHTEN THE BOLTS USING ALLEN KEY.</p>



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver

	
<p>STEP 11 ADJUST THE ADJUSTER THAT HAS ALREADY BEEN ASSEMBLED TO THE LEGS TO STABILIZE YOUR UNIT.</p>	<p>STEP 12 ATTACH DRAWER LEFT AND RIGHT TO DRAWER BACK USING 1 1/4" FLAT HEAD SCREWS. SLIDE DRAWER BASE INTO THE GROOVE. ATTACH DRAWER FRONT TO DRAWER LEFT AND RIGHT USING 1 1/4" FLAT HEAD SCREWS.</p>


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver


	
<p>STEP 13 ATTACH DRAWER SUPPORT TO THE BOTTOM SIDE OF DRAWERS USING 1 1/4" FLAT HEAD SCREWS.</p>	<p>STEP 14 LOOSEN SLIGHTLY THE SCREWS PRE-INSTALLED ON THE BACK OF THE DRAWER FRONTS.</p>

PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver



STEP 15 INSERT THE DRAWER INTO THE UNIT, THEN ADJUST THE DRAWER FRONT PANEL LEFT OR RIGHT AND UP OR DOWN UNTIL THE DRAWER GAPS LOOK PROPORTIONAL.



STEP 16 PULL THE DRAWER OPEN SLOWLY AND RE-TIGHTEN THE SCREWS FROM STEP 14. MAKE SURE THE FRONT PANEL DOES NOT MOVE AND LOCK THE DRAWER FRONT PANEL INTO POSITION WITH 3/4" FLAT HEAD SCREWS.



STEP 17 SLIDE THE DRAWERS INTO UNIT.