

About the Wood and Finish

This product has been carefully crafted of: MDF, solid pine wood and/or pine veneers. These materials derive from plantations, a renewable and well managed forest, therefore, not endangering the environment. The highest quality standards have been implemented to assure a sturdy and reliable product. Due to the natural variances in the graining of wood, you may notice

subtle differences in the shading and tone of the color stain, warp, holes, wood knots and also small cracks. This is not a defect.


But rather a result of the natural beauty of the wood itself.



Care and maintenance:


Dust when needed using a smooth, dry cloth. Household furniture polish can be used occasionally to restore luster.

BD01409 TWIN LOFT BED




Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.
"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"




* Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!
* Please assemble on a clean soft surface to avoid damage.



Tools Required



(Not included)




(Not included)

IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY


















MANUFACTURER LABEL



Identifying the Hardware


Identify the hardware using the illustrations below.

A		Qty 16	1 $\frac{1}{16}$ " Wooden Dowel (10 x 40mm)
B		Qty 14	1 $\frac{1}{16}$ " Wooden Dowel (8 x 40mm)
C		Qty 08	1 $\frac{1}{16}$ " Black connection (10 x 40mm)
D	 	Qty 12	5 $\frac{1}{8}$ " Bolt (7,0 x 130mm)
E	 	Qty 20	2 $\frac{3}{4}$ " Bolt (7 x 70mm)
F	 	Qty 04	2" Bolt (7 x 50mm)
G	 	Qty 08	$\frac{1}{4}$ " x 2 $\frac{3}{4}$ " Bolt ($\frac{1}{4}$ " x 70mm)
H		Allen Qty 01 4mm	
I	 	Qty 06	1 $\frac{1}{16}$ " Bolt (7 x 40)
J	 	Qty 32	1 $\frac{3}{16}$ " Screw (4 x 30mm)
K		Qty 08	$\frac{1}{4}$ " Elliptical Nut
L		Qty 02	Wooden spacer 2 $\frac{15}{16}$ " (75mm)
M		Qty 04	
N	 	Qty 12	$\frac{5}{8}$ " Screw (4 x 16mm)



*Actual size of screws and bolts, for measurements checking.

01 Black Connection






A **16**
1 $\frac{1}{16}$ " Wooden Dowel

B **14**
1 $\frac{1}{16}$ " Wooden Dowel


C **08**
1 $\frac{1}{16}$ " Black connection

02

(x2)



CAUTION
EACH POST HAVE
A DIFFERENT NUMBER







5 1/8" Bolt

Qty
12

H Allen wrench Qty 01





03





04



Attention Detail



05

**F**



2" Bolt

Qty 04

H Allen wrench


Qty 01

06


**J** **1 3/16" Screw** **Qty 26****L** **Wooden spacer** **2 15/16" (75mm)** **Qty 02**

The first slats must be fixed to the end of the side rail bracket.
After fixed the first slat use the hardware letter L to help define the space between each next slats.
Use 1-L on the left side rail and 1-L on the right side rail


07 ACESS





08



LEFT ACESS OPTION




RIGHT ACESS OPTION




09

SLIDE






10





LEFT SLIDE OPTION

RIGHT SLIDE OPTION



N (5/8" Screw) Qty 02

11



TOY BOX IS OPTIONAL

