
















# ASSEMBLY INSTRUCTION












ITEM : C8370FPL / C8370QPL

## PARTLIST

|  |  |  |   |  |
|--|--|--|---|--|
| 1<br><br>HEADBOARD CUSHION x1 | 2<br><br>FOOTBOARD CUSHION x1 | 3<br><br>FOOTBOARD LEG x2                | 5<br><br>SIDE RAIL x2        | 6<br><br>SIDE RAIL x2       |
| 7<br><br>SIDE RAIL LEG x2     | 8<br><br>SLAT WITH NUT x4     | 9<br><br>SUPPORT LEG WITH HANGER BOLT x4 | 10<br><br>SLAT x8            | 11<br><br>CENTER SUPPORT x2 |
| 12<br><br>SOCKET x24          | 13<br><br>SUPPORT RAIL x2     | 14<br><br>HEADBOARD LEG x2               | 15<br><br>SIDE RAIL COVER x2 | 24<br><br>VELCRO TAPE x2    |


\*All parts needed are shown in above picture.  
Numbers only indicate the specific parts for easy assembly.

## HARDWARE


|   |   |   |   |  |
|---|---|---|---|--|
| A<br><br>JCBB SCREW<br>M8 x 40MM x4         | B<br><br>JCBC SCREW<br>M6 x 15MM x14    | C<br><br>JCBC SCREW<br>M6 x 20MM x8    | D<br><br>JCBC SCREW<br>M6 x 35MM x4 | E<br><br>SPRING WASHER<br>M6 x 12MM x4 |
| F<br><br>FLAT WASHER<br>M6 x 19MM x4       | G<br><br>SPRING WASHER<br>M8 x 13MM x4 | H<br><br>FLAT WASHER<br>M8 x 22MM x4 | I<br><br>L - KEY<br>M4 x 100MM x1  | J<br><br>L - KEY<br>M5 x 65MM x1      |
| K<br><br>SUPPORT LEG<br>ADJUSTABLE FEET x4 |   |   |   |  |

# ASSEMBLY INSTRUCTION


## STEP 1




## STEP 2



## STEP 3



## STEP 4



STEP 5

This diagram illustrates the fifth step of the assembly process: attaching the headboard to the bed frame. The main illustration shows the headboard being positioned against the frame, with callouts 13 and 14 indicating the connection points. A circular inset provides a detailed view of the attachment mechanism. In this inset, callout 13 points to the headboard's side rail, and callout 14 points to the bed frame's side rail. The connection is made using a bolt (D) and a washer (E) that pass through the frame rail and the headboard rail, secured by a nut (F). A cam lock (I) is used to tighten the nut. Arrows indicate the direction of assembly.

**STEP 6**


This diagram illustrates the final step of assembling the bed. The main illustration shows the bed frame with the headboard being attached. Two callouts, labeled 7 and 13, point to the corner joints of the frame. A circular inset provides a detailed view of the connection point. In this inset, a metal bracket (labeled I) is shown being secured to a horizontal frame rail (labeled 13) using a bolt (labeled E) and a washer (labeled F). The headboard is positioned at the top of the frame, ready to be fastened.

STEP 8


The diagram shows a long, thin rectangular block. A small cube labeled '2' is at the bottom left, with an arrow pointing right towards the block. A small cube labeled '12' is at the bottom right, with an arrow pointing left towards the block. A large 'x8' is written above the block. A circle with the number '10' is located on the block.

# ASSEMBLY INSTRUCTION


STEP 9




STEP 10



STEP 11



STEP 12



ASSEMBLY  
COMPLETED