


ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED



Allen Wrench
(Included)



**2 - People
Recommended**

ASSEMBLY RATING



EASY ————— DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!


☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Save the instructions and store
any supplied tools for later
maintenance.

Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.




After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

SOFA TABLE




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

#1 1pc




Glass Top

#2 1pc



Base

#3 1pc



Support Leg

HARDWARE

#A 2pcs



Bolt $\varnothing\frac{1}{4}$ "x3/8"

#B 2pcs



Bolt $\varnothing\frac{1}{4}$ "x3/8"

#C 4pcs



Bolt $\varnothing\frac{1}{4}$ "x1-1/2"

#D 4pcs



Flat washer $\varnothing\frac{3}{4}$ "

#E 4pcs












Adjuster \varnothing 1-1/2"

#F 1pc



Allen wrench

Packed in 2 cases

Carton	Designation	Part	Hardware
	Glass	 #1	
	Base	 #2	(#A) 2pcs  Bolt $\varnothing \frac{1}{4}" \times 3/8"$ (#B) 2pcs  Bolt $\varnothing \frac{1}{4}" \times 3/8"$ (#C) 4pcs  Bolt $\varnothing \frac{1}{4}" \times 1-1/2"$ (#D) 4pcs  Flat washer $\varnothing 3/4"$ (#E) 4pcs  Adjust $\varnothing 1-1/2"$ (#F) 1pc  Allen wrench
	Leg	 #3	

ASSEMBLY INSTRUCTIONS

1

Part #1 x1pc


Part #3 x1pc

Hardware #A x2pcs

Hardware #B x2pcs

Hardware #F x1pc

- I. Carefully place the glass top (#1) onto a protected surface.
- II. Insert Bolts (#A) to the squared end of the Support leg (#3).
- III. Align the one support leg (#3) to the pre-drilled holes on the glass top (#1).
- IV. Insert 2 bolts (#B) and secure.



ASSEMBLY INSTRUCTIONS

2

Part #2 x1pc

Part #3 x1pc


Hardware #C x4pcs

Hardware #D x4pcs


Hardware #E x4pcs

Hardware #F x1pc

- I. Align the pre-drilled holes on the base (#2) to the support leg (#3).
- II. Prepare 4 bolt assemblies by inserting the flat washer (#D) to the bolt (#C) and secure using the Allen wrench (#F).
- III. Insert the adjusters (#E)



3



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.