


# Rattan 3 Drawer Desser

ApplicableItemNO. : H0096




**2 HOURS**  
ASSEMBLY TIME

**2 PEOPLE**  
REQUIRED FOR ASSEMBLY

**2 x 1 m**  
FLOOR SPACE REQUIRED


















## Product Diagram








### After-sales Support


If there are any parts missing, damaged or defective, please feel free to contact us for support via the following email. Information required is listed on Page 3.

Email: [service@anmytek.com](mailto:service@anmytek.com)


<b>Hardware List</b>			
 <p><math>\Phi 6 \times 35 \text{mm}</math> A <math>\times</math> 37</p>	 <p><math>\Phi 15 \times 10 \text{mm}</math> B <math>\times</math> 37</p>	 <p><math>\Phi 6 \times 30 \text{mm}</math> C <math>\times</math> 24</p>	 <p><math>\Phi 4 \times 35 \text{mm}</math> D <math>\times</math> 19</p>
 <p><math>\Phi 3 \times 12 \text{mm}</math> E <math>\times</math> 30</p>	 <p><math>\Phi 3 \times 16 \text{mm}</math> F <math>\times</math> 8</p>	 <p>G <math>\times</math> 8</p>	 <p>H <math>\times</math> 2</p>
 <p>I <math>\times</math> 2</p>	 <p><math>\Phi 4 \times 12 \text{mm}</math> J <math>\times</math> 2</p>	 <p><math>\Phi 4 \times 40 \text{mm}</math> K <math>\times</math> 2</p>	 <p><math>\Phi 4 \times 25 \text{mm}</math> L <math>\times</math> 6</p>
 <p>CL <math>\times</math> 3</p>	 <p>CR <math>\times</math> 3</p>	 <p>DL <math>\times</math> 3</p>	 <p>DR <math>\times</math> 3</p>
 <p>M <math>\times</math> 3</p>			


## Step 1

A	×8
	
C	×4
	
E	×18
	
CL	×3
	
CR	×3
	




## Step 2






B	×8
	





Step 3




Step 4



A × 4	J × 2
	
C × 4	I × 2
	
B × 4	
	




## Step 5







## Step 6

C	×4
	
D	×4
	







## Step 7

A	× 4
	
B	× 4
	
C	× 4
	





## Step 8

A	× 6
	
C	× 8
	
B	× 6
	






## Step 9



**Kindly note:** This is a very important step that can not be skipped. Please follow the step to screw the plastic pieces into the corner of the back panel tightly. If you forget to fix these pieces, it may result in the instability of the whole item.





## Step 10



X3





## Step 11





x3


## Step 12





x3


## Step 13

K	× 2
	
H	× 2
	



## Step 14

M	× 3
	
L	× 6
	



## WALL FIXING GUIDE

**NOTE:** Supplied wall plugs are only suitable for use in masonry walls.

If you have any doubts about using the correct plug for your wall, please seek professional advice. Failure of the product due to using incorrect fixings is the responsibility of the installer.



### IMPORTANT:

When drilling into walls, always check for hidden wires or pipes, etc.



## Tips & Tricks


Make sure that the hardware used is suitable for supporting your unit.

Please consult a qualified trades person if unsure.

- ☒ If you are unsure, please select a larger screw and wall plug.
- ☒ Ensure that you use the recommended drill bit to match the wall plug and hole size.
- ☒ Take extra care when drilling high walls, ceiling and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid splitting or cracking.
- ☒ Ensure that wall plugs are well fitted and are a tight fit in the drilled hole.


## Types of Walls

Use one of the following types of wall plug (not included) if your walls are made of brick, breeze block, concrete, stone or wood. Screws may be able to be fixed directly to solid wood walls as they will provide a secure anchor point.




**1. General Purpose Wall Plug**

Generally, aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.




**2. Plasterboard Wall Plug**

For use when attaching light loads onto plasterboard partitions.




**3. Cavity Fixing Wall Plug**

For use with plasterboard partitions or hollow wooden doors.




**4. Cavity Fixing Heavy Duty Wall Plug**

For use when fitting or supporting heavy loads such as shelving and wall cabinets.



**5. Hammer Fixing Wall Plug**

For use with concrete block or brick walls, or walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.



**6. Shield Anchor Wall Plug Heavy Loads**

For use with concrete or brick walls, or for use with heavier loads such as TV & HiFi speakers and satellite dishes, etc.