


ASSEMBLY INSTRUCTIONS

24 INCH BATH VANITY-CABINET





Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"


*** Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!**
*** Please assemble on a clean soft surface to avoid damage.**



Tools Required



(Not included)



(Not included)

IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

Thank you for buying our products.

Please read the installation manual carefully before installation,

we need you to follow the instructions on the accessories and hardware

step by step assembly complete, our instructions are very detailed.

Products are environmentally friendly products,

Please rest assured that you do not soak in water, do not place very heavy items,

do not malicious push and pull,

if you have any problems in the process of assembly and use, please contact us.

Thank you again for your purchase of our products,

I wish you a happy life.


Slides Must Be Separated Before Assembly.
After Separated, Set Aside Until Needed for Assembly.

Las diapositivas deben separarse antes del montaje.
 Después de la separación, déjelo a un lado hasta que sea necesario.


Les glissières doivent être séparées avant l'assemblage.
 Après la séparation, mettez de côté jusqu'au moment de l'assemblage.

Pay attention when connecting !
The sliding module must be at the front end.

STEP 1 : Extend Slide
Extender la diapositiva




STEP 2: Push Lever UP
Empujar hacia arriba
Lever le levier




Push lever for the left of drawer ,
press the lever for the right of drawer.

STEP 3: Remove Runner
Quitar el corredor
Enever le coureur


















Detail View - CABINET






















Identifying the Hardware-Identify the hardware using the illustrations below.


Part List - WF315816



1		2	
	Side Panel (L) - 1pc		Side Panel (R) - 1pc
3		4	
	Mid Panel - 1pc		Drawer Fake (L) - 1pc
5		6	
	Drawer Fake (R) - 1pc		Rear Panel Top - 1pc
7		8	
	Rear Panel Bottom - 1pc		Frame Bottom - 1pc
9		10	
	Foot Cabinet - 4pcs		Door cabinet - 1pc
11		12	
	Drawer Face - 2pcs		Drawer Rear - 2pcs
13		14	
	Drawer Side(L) - 2pcs		Drawer Side(R) - 2pcs
15			
	Drawer Bottom - 2pcs		


Hardware List - WF315816

A	 ø13x1/4"x28mm Hex-Head bolts(4pcs)	B	 ø13x1/4"x38mm Hex-Head bolts(8pcs)	C	 ø13x1/4"x50mm Hex-Head bolts(2pcs)
D	 ø1/4"x16x1mm Washer(14pcs)	E	 ø6x35mm Three in one bolts(16pcs)	F	 ø14.5x12mm Three in one lock(16pcs)
G	 Handle (6pcs)	H	 ø5/32"x20mm Handle screw (4pcs)	I	 ø5/32"x32mm Handle screw (2pcs)
J	 ø8xø4x32mm Round head screw(16pcs)	K	 ø8xø4x25mm Round head screw(2pcs)	L	 Damping hinge (2pcs)
M	 ø7xø3.5x15mm Flat head screw(12pcs)	N	 ø300x35mm Slide rails (4pcs)	O	 ø298x18mm Slide rails (4pcs)
P	 ø6xø3x12mm Flat head screw(24pcs)	Q	 ø8x30mm Wood dowel(16pcs)	R	 4mm Allen key(1pc)
S	 Anti fall hardware(1set)				


STEP: 1





B	D
	
8PCS	8PCS





STEP: 2




E

16PCS




STEP: 3


N		P	
4PCS		12PCS	




POSITION OF SCSEW







STEP: 4

K	
2PCS	











STEP: 5

F		Q	
8PCS		4PCS	




STEP: 6


A		C		D		Q	
4PCS		2PCS		6PCS		4PCS	




STEP: 7





F		Q	
2PCS		8PCS	





STEP: 8




F	
6PCS	








STEP: 9

L	M
	
2PCS	4PCS




STEP: 10


G	H	M
		
4PCS	4PCS	8PCS




Use the screws to adjust up or down




Use the screws to permanent








Use the screws to adjust left or right








Use the screws to adjust in or out




STEP: 11

J	G	I	O	P
				
16PCS	2PCS	2PCS	4PCS	12PCS




x2



POSITION OF SCREW



STEP: 12




STEP: 13




STEP: 14

**Install the sink on the cabinet with glue.
Let stand for 24 hours**




***Silicone glue is not included in the package to comply with safety regulations in certain shipping conditions.**

STEP: 15



HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw

clockwise to move the door further away from the side of the cabinet

anticlockwise to move the door closer to the side of the cabinet




② ④ Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up

anticlockwise to move the door down



③ Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

clockwise to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

