

E 2x



E1 2x



E2 2x



M6x16



3 24x

S4



10 1x

<9> Connect Part E2 to the Support Bar (Part D & D1) using screws #3 just as shown in the diagram.



12

Connect Part E & E1 & E2 to the main frame (Part C1 & C) using screws #3 just as shown in the diagram above.



M6x16

3

2x



S4







10



1x

<10> Attach Part F to the main frame using screws #3 as shown below.





<11> Put on Part H,F,U,H and screws #3 (2 PCS) just as shown in the diagram. Then connect 2 Parts H to Part F using Part U & screws #3.



Attach Part T1 to the Middle Beam (Part H) using screws #2.



M6x16



3 12x







S4


10 1x

<12> Connect Part G to the Roof Support Bar (Part H) using screws #3 (2 PCS) as shown below.





<13> ⚠ Please Note: remember to wear gloves.



Put on Part J1,H,T2,J and screws #3 as shown above. Then connect Part J1 & J to Part H using Part T2 & screws #3(3 PCS).

Put on Part J1,T and screws #3 as shown above. Then attach Part J1 to the Corner Roof Bar (Part D & D1) using screws #3 from bottom to top through Part T.



P 1x



P1 1x




11 1x


<14> Connect Part P to Part P1 using screws #11 as shown below.





Please Note: Parts P & P1 are easy to slide, please wear gloves when installing.
(Part P&P1 can increase the Weight capacity of the metal top.
It's especially necessary to use in heavy rain and snow.
At ordinary times we suggest you choose to put it away.)



<15> Connect Part P to Part F1 as shown below.



<16> Please wear gloves. Then connect Part Z & Z1 to the Roof Panels (Part M, M1, M2) respectively as shown below.



(M) 14x



(M1) 2x



(M2) 2x



(Z) 32x



(Z1) 4x





(X) 2x




X 2x

<17> Please wear gloves.
Then push Parts M,M1,M2 to the Top Roof (Part F1) as shown below.



Tips: Please place the Roof Panels
in the position and stacking mode
as shown in the diagram.






Y 90x




M6x20

4 6x



M6x28

5 24x



M6x45

6 60x




9 84x






S4

10 1x


<18> Step a: Affix Roof Panels to Part H with screws #4 (3 PCS) & Part Y as shown below.



Step b: Affix Roof Panels to Part C2 or C3 with screws #5 (6 PCS) & Part 9 & Part Y as shown below.



Step c: Affix Roof Panels to Roof Bar with screws #6 (6 PCS) & Part T2 & Part Y & Part 9 as shown.




Step d: Affix Roof Panels to Part J or J1 with screws #6 (12 PCS) & Part Y & Part 9.

<19>

Step a: Attach Part L or L1 to the Roof with screws #5 & Part Y, 9.

Step b: Attach Part K1 to Roof M2 with screws #6 & Part Y, J1, K1, 9.



Step c: Attach Part L & L1 to the Roof M with screws #6 & Part V2, 9.



V 2x




V1 4x



M6x16

3 2x



M6x45

6 4x



ST5x13

8 4x






9 4x



S4

10 1x


<20> Connect Part V to the Top Roof Beam (Part K & k1 & F1) using screws #8 & #3.




Put on screw #6, Part V1, Part K, Part M1, Part L and Part 9 as shown in the diagram. Then connect Part L & K with Part V1 & M1 using screw #6 & #9.

Connect Part P to Part F1 as shown below.

<21> (Part P&P1 can increase the Weight capacity of the metal top.
It's especially necessary to use in heavy rain and snow.
At ordinary times we suggest you choose to put it away.)



Gable Roof Design Wood Grain Gazebo Assembly Manual



READ ALL INSTRUCTIONS BEFORE USE



Warning&Attention

-This gazebo is not a toy.Children are not allowed to assemble or disassemble.Please take care of children,do not let them play around when assemble or disassemble.

-Adults only for assemble or disassemble this product.

-This product is constructed with heavy duty frame,please do not lean or climb before it finish assembling.

-Even though our hardtop gazebo is sturdy,please do not stand under the gazebo during a lightning storm.

-DO NOT use this gazebo if any parts show signs of instability or damage.



Two or more people are needed for assembly.



Find out and use the hex keys in the box.



One or more ladders are necessary.



A phillips screwdriver is required.



Please wear protective glove before assembly.



Please don't fully tighten the screws prior to complete assembly.



















Please wear a safety hat.

























You may need prepare a drill.






















Part list


	
A 4x Pole	C 2x Beam
	
C1 2x Beam	C2 2x Inside Beam
	
C3 2x Inside Beam	D 2x Corner
	
D1 2x Corner Roof Bar	E 2x Roof Solidifying Bar
	
E1 2x Roof Solidifying Bar	E2 2x Roof Solidifying Bar
	
F 1x Top Roof Beam	F1 1x Top Roof Beam
	
G 3x Top Support Bar	H 6x Roof Bar
	
J 8x Solidifying Bar	J1 8x Solidifying Bar


Part list

		
K 2x Finishing Bar	K1 2x Finishing Bar	
		
L 2x Finishing Bar	L1 2x Finishing Bar	
		
M 14x Roof Panel	M1 2x Roof Panel	
		
M2 2x Roof Panel	N 4x Corner Solidifying Bar	N1 4x Corner Solidifying Bar
		
P 1x Middle Support Pole	P1 1x Middle Support Pole	
		
B 4x Base	B1 8x Joint Cover	B2 8x Joint Cover
		
Q1 1x Joint Bar	R 4x Joint Bar	Q 4x Joint Cover
		
S1 2x Joint Cover	S2 2x Joint Cover	S 2x Solidifying Bar
		
T 8x Joint Cover	T1 6x Joint Cover	

Part list

 T2 12x Joint Cover	 U 3x Joint Cover	 V 2x Finishing End	 V1 4x Joint Cover
 V2 2x Joint Cover	 W 3x Hook	 X 2x Gloves	 Y 132x Spacer
 Z 32x Metal Bracket	 Z1 4x Metal Bracket	 1 40x M5x16	 2 6x M6x10
 3 238x M6x16	 4 6x M6x20	 5 56x M6x28	 6 74x M6x45
 7 32x M6x15	 8 52x ST5x13	 9 130x	 10 1x S4 S6
 11 1x			





A 4x



B 4x



B1 8x



B2 8x



M5x16

1 40x



M6x16

3 12x




S4

10 1x

5

<1> ⚠ Please Note: remember to wear gloves.



Put on Part B2 and screw #1(3 pcs) just as shown in the diagram above. Then connect Part B2 to A.

Put on Part B1 and screw #1(2 pcs) just as shown above. Then connect Part B1 to A.

Put on Part B and screw #3(12 pcs) just as shown above. Then connect Part B to A.

<2>



C 2x




C1 2x



C2 2x



C3 2x



R 4x



Q 4x



T1 6x



M6x16


3 32x




ST5x13

8 16x


6




Put on Part Q and screw #3(4 pcs)
just as shown on the left.
Connect Part C & C1 with Part Q.




Then put on Part R and screw
#8(4 pcs) just as shown.
Connect Part R to the finished
beam (Part C & C1).



Connect Part C3 & C2 with Part Q
using screws #3(8 pcs).



Attach Part T1 & R to the fin-
ished beam(C3 & C2) using
screws #8(4 pcs).



Attach Part T1 to the finished beam(C2
or C3) using screws #3(2 pcs).



D 2x



D1 2x



S 2x



S1 2x



S2 2x



T 8x



M6x16


3 28x












10 1x


7

<3>






<4> Put on Part F,F1 and Q1 screw #3 just as shown. Connect Part F & F1 with Part Part Q2.



<5> Attach Part W to Part G.





M6x16

3

16x



M6x15

7

32x


S4


S6

10

1x

<6> Put on Poles (Part A) & Beams (C,C1,C2,C3) and screws #3,#7 just as shown. Connect Part C & C3 to Part A. Replicate for 4 times.





(N) 4x



(N1) 4x



(R1) 4x



M6x16

(3) 32x



ST5x13

(8) 32x




(10) 1x

<7>

Connect the frame with Part N & N1 using screws #3.

Then finish connecting beams with Part R1 using screws #8 just as shown in the diagram.





M6x16

3 12x

S4



10 1x

<8> Just as shown in the diagram below, connect Poles(Part A) and Beams (Part D1 & S2) using screws #3.

