


# Greenhouse

## Assembly Instructions



Size: 252Lx190Wx193H cm

NB250-1

### **IMPORTANT**

You must read these instructions carefully before you start to assemble this greenhouse.

Please ensure that you find all parts in the carton box in the correct type and quantity as mentioned in the list illustrated in every page accordingly.

Please carry out the steps in the order set out in these instructions.

Do not tighten the steps in the greenhouse until completing on the assembly of the polycarbonate panels.

Keep these instructions in a safe place for future reference.

## **SAFETY ADVICE**

We strongly recommend the use of work gloves during assembly.  
Do not attempt to assemble the greenhouse in windy or wet conditions,  
Do not touch overhead power cables with the aluminum profiles.  
Always wear shoes and safety goggles when working with extruded aluminum.  
Dispose of all plastic bags safety-keep them out of reach of small children.  
The greenhouse must be positioned and fixed on a flat level surface.  
Do not lean against or push the greenhouse during construction.  
Keep children away from the assemble area.  
Do not position your greenhouse in an area exposed to excessive wind.  
Do not attempt to assemble this greenhouse if you are tired ,have taken drugs or alcohol or if you are prone to dizzy spells.  
If using a step ladder or power tools ensure that you follow the manufactures safety advice.  
Hot items such as recently used grills, blowtorches etc.must not be stores in the greenhouse.  
Ensure there are no hidden pipes or cables in the ground before inserting the pegs.

## **GENERAL ADVICE**

This is a multi-part assembly, Allow at least 300 minutes for assembly.  
Selecting a site-choose a sunny level position away from overhanging trees.  
If you are fixing your greenhouse directly to a solid concrete foundation use the pre drilled holes in the metal base supplied.  
The component parts should be checked and laid out close at hand.  
Keep all small parts(screws etc)in a bowl so they do not get lost.  
Note that the door is hinged on the right hand side and therefore opens tothe right.  
Keep roof clear of snow and leaves.

## **CARE & MAINTENANCE**

When your greenhouse needs cleaning, use a mild detergent solution and risen with cols clean water.  
Do NOT use acetone, abrasive cleaners or other special detergents to clean the clear panels.

## **TOOLS & EQUIPMENT REQUIRED**




Silicone sealant & applicator bradawl phillips screwdriver step ladder.  
Tape measure large hammer scissors  
Work gloves Drill spirit level Lubricant see over for cantents plastic or rubber mallet 0.08" metal drill bit  
If help is required seek professional advise within store.



# TOOLS & EQUIPMENT REQUIRED



## Protective Equipment:

1. Helmet
2. Glove
3. Long Sleeve Cotton Overalls
4. Emergency Medicine Cabinet
5. Eye Shield





## Measure (metric):

1. The Tape (5 m)
2. Angle Square
3. Level Meter



## Installation Tool:


1. Triangle Stairs≈1.5m Height
2. Spanner 10mm (Ratchet Wrench is better)
3. Electric screwdriver+10mm hex bolt sleeve(suggest)
4. Wooden Mallet
5. Marking Pen
6. Silicon
7. Knife
8. Phillips screwdriver



Silicon

## OTHER CAUTIONS

















1. 3-4 people required, one is for measuring & taking marks to ensure the installation dimension ,the second person is responsible for the installation and the last one do as assistant and assure the safety.
2. High-power electric tools are required, ensure the normal work of them and highly pay\attention to electric safety.
3. Be careful when using the kind of blunt tools, like hammer.
4. Wearing long sleeve cotton overalls,gloves and helmet during installation and wea safety glasses when using power tools.
- 5.No up watching when working height, or the drop screws may hurt your eyes and suffocation causing accide ntally when fall into your mouth.
6. No climbing, No standing on the tent to avoid falling down.
7. If injuries immediately, using the first-aid kit to stop bleeding,bind up,In case of emergency , taken immediately to a nearby medical institutions.



NB250-1























PARTS LIST OF NB250-1


PART	NO.	Qty.	MM		PART	NO.	Qty.	MM		
	D1	1	1647			9	2	1653		
	D4	1	1647			10L	1	1674		
	D2	1	621			10R	1	1674		
	D3	3	621			19	6	1197		
	D3	3	621			20	6	1142		
	W1	1	588			12	4	583		
	W2	2	500			15	2	578		
	W2	2	500			13	1	630		
	W3	1	588			14	1	1838		
	W4	1	380			22	12	1200		
	4	2	1219			17	2	1219		
	4-1	2	1219					18	1	1240
	5	1	1838					25	4	1217
	6	1	1838			26	1	580		
	7	4	1197							
	16	4	1142							
	8	4	1219							

PART









PARTS LIST OF NB250-1

NO.	Qty.		NO.	Qty.		NO.	Qty.			NO.	Qty.	
B1	6		B10	2		S2	13			F1	10	ST3.8- 10mm 
B3	2		B11	2		S5	2			F2	8	ST4.8- 16mm 
B4	4		B12	1		S6L	2			F4	154	M5- 8mm 
B5	4		T1	3		S6R	2			F6	2	M5- 20mm 
B6	2		T2	6		S7L	1			F7	32	M6- 14mm 
B7	1					S7R	1			F8	2	4-18mm 
						S8	1					
						S9	1					
						S10	2					








SUMMARY STATEMENT FOR POLYCARBONATE PANEL



The UV-protected side of the sheet is covered with transparent film and must face towards the sun.







W1 x1	
W2 x2	
W3 x1	
W4 x1	
S8 x1	
S9 x1	
F2 x4	
F8 x2	
P2 x1	











7x4	
5x1	
4x2	
4-1x2	
6x1	
B10x2	
F4x8	
F7x8	




9 x1	
12 x1	
23 x1	
B1 x2	
F4x8	
S2x1	
P3 x1	







9 x1




12 x1




23 x1




B1 x2









F4x8




S2x1






P3 x1




























13 x1	
B4 x2	
F4x 2	
P4L x1	
P4R x1	
P7 x1	















	
10Lx1	
10Rx1	
23 x2	
F4x8	
S2x2	
P3 x2	














	
12 x2	
15 x1	
14 x1	
F4x10	
S2x1	
P5 x1	































	
16 x 2	
B4 x 2	
F4 x 8	
F6 x 2	



























26x2





T1x3




T2x6




F4x2




a




a1






b



c








18 x1	
S7L x1	
S7R x1	





25 x 4	
S10x2	
S2x8	
P8 x 8	
P9 x 7	
P10x1	





15 x 1	
B7 x 1	
B1 x 2	
S5 x 2	
S6L x 2	
S6R x 2	
F4 x 4	

