


Shower Door Installation Instructions



Reversible for a left or right door installation.

**Please do not return the product to the store.
Contact us with any questions.**

Model Specific Preparation







REQUIRED:


Verify threshold and wall with a level.

1/4"(6mm) Maximum out of plumb adjustment from top to bottom

Threshold must be level.



PACKAGE CONTENT



PACKAGE CONTENT












PART#	DESCRIPTION	QTY
A	Wall Jamb	1
B	Stationary Glass	1
C	Top Bracket	1
D	Bottom Bracket	1
E	Glass Door	1
F	Bottom Anti-Water Strip	1

PART#	DESCRIPTION	QTY
G	Support Rod	1
H	Handle	1
I	Wall Jamb cover	2
J	Top pivot sleeve	1
K	Bottom pivot sleeve	1






NOTE

Inspect all parts for missing prior to installation!
Contact us for any part missing.


PACKAGE CONTENT



HARDWARE CONTENT



Additional spare parts are included.




NOTE

Inspect all parts for missing prior to installation!
Contact us for any part missing.


TOOLS REQUIRED

Drill Bits




Ø1/8" & Ø1/4" (3&6mm) dia.
HSS


Phillips screw driver




Electric hand drill




Level




Silicone gun




Measuring Tape




Soft Head Hammer




Marking Pencil



Utility Knife




Sealant




MASONRY DRILL
BIT FOR TILE
Ø6mm




Safety Glasses




Glove




Carpenter's Squarer




Masking or painter's
tape




Hack Saw




Metal File



Glass suction
Handle



Flat head
screwdriver



SAFETY INFORMATION


CAUTION

Please carefully read the following important safety information before handling or installing this shower door . There is a risk of serious injury while handling this product.


To minimize these risks, please note:

- Always wear safety glasses and gloves while handling.
- Always follow the installation instructions.
- Inspect glass for damage before installation.
- Extreme caution should be taken while handling the glass during installation as the tempered glass may shatter if in contact with a hard surface.
- Do not cut or modify the tempered glass as it will shatter if cut.
- Carefully remove product from packaging and keep packaging until installation is complete.
- Inspect all parts for damage or missing; if there is damage or part missing to the unit prior to installation, please contact customer service at the number provided in this guide.
- Cover the drain with tape to prevent the loss of small parts.
- The shower base and finished walls should be installed before beginning the shower door installation.
- During the installation, protect the shower floor with a drop cloth to avoid damage.
- This product should be installed by two people who are familiar with construction requirements. Professional installation is recommended!
- Keep this installation manual for future reference.

NOTE: Two people should perform this installaton.



Model Dimensions



configuration dimensions:

A Product Height	B Mod I width	Installation width
58"	33 1/4"	33 1/4"~34"
58"	35 1/4"	35 1/4"~36"

NOTE


This model is reversible for right or left-hand door installation. The left-hand door installation is shown throughout this manual. For the right-hand door installation, simply begin on the opposite wall and reverse the orientation of the installation steps shown.

1

Install **Wall Jamb(A)**

NOTE

1. Determine your starting point from the edge of bathtub (3/8" (10mm) is recommended) and mark the position as Fig.a .
2. Once the **Wall Jamb(A)** are vertical, mark the holes with a pencil as Fig.b .



2 Drill screw holes for **Wall Jamb(A)** and insert in the **Wall Anchor(aa)**.

NOTE

1. Drill holes with $\Phi 6\text{mm}(1/4")$ drill bit as Fig.a.
2. Insert the **Wall Anchors(aa)** as Fig.b.

Fig.a (1/4")
 $\Phi 6\text{mm}$






Fig.b



NOTE


- If a Stud is present behind the wall:
drill $\Phi 1/8"$ (3mm) pilot holes into the stud and use the ST4.0x40mm **Screws(bb)**
OR
- If NO Stud is present behind the wall:
drill $\Phi 1/4"$ (6mm) holes and insert the **Wall Anchors(aa)** and use the ST4.0x40mm **Screws(bb)**.

3

Install **Wall Jambs(A)**.

NOTE


1. Fix **Wall Jambs(A)** with **Screw(bb)** as Fig.a .



4 Install Bottom Bracket(D).



NOTE

1. Install **Bottom Bracket(D)** as Fig.a and Fig.b .



Always towards the bottom

Fig.a




CAUTION: Do not put glass directly on the ground

5 Install **Stationary Glass(B)**.

NOTE

1.Insert the **Stationary Glass (B)** to the **Wall Jamb(A)**, the max adjustment is 3/4"(20mm) as Fig.a .



Note: The shower door can be installed left or right, according to the need to determine the installation direction.



CAUTION: Do not put glass directly on the ground

6




Fix Stationary Glass(B)

NOTE




1. Drill 3 holes on the inside of the **Wall Jambs(A)** with 1/8"(3mm) drill bit as Fig.a .
2. Install **Screws(dd)** and screw cover cap **Washers(ee)** as Fig.b .
3. Install **Screw caps(cc)** as Fig.c .



CAUTION: Do not put glass directly on the ground






Take care not to drill into the glass




7-1 Install **Support Rod(G)**

NOTE

1. Put the one side of **Support Rod (G)** to the **Stationary Glass(B)**, adjust the position as Fig.a .
- 2.Keep it level and mark a fix point for the **Support Rod (G)** to the wall as Fig.b .




7-2 Install Support Rod(G)



NOTE

- 1.Remove the wall bracket from the **Support Rod(G)** as Fig.a
- 2.Mark a point on the screw hole of the bracket to the wall as Fig.b.
3. Drill hole on the marked point as Fig.c .
4. Fix a **Wall Anchor(aa)** to the wall as Fig. d.





NOTE

- If a Stud is present behind the wall:
drill $\phi 1/8''$ (3mm) pilot holes into the stud and use the ST4.0x40mm **Screws(bb)**
OR
- If NO Stud is present behind the wall:
drill $\phi 1/4''$ (6mm) holes and insert the **Wall Anchors(aa)** and use the ST4.0x40mm **Screws(bb)**.

7-3 Install **Support Rod(G)**

NOTE

1. Fix the wall bracket with **Screw(bb)** as Fig.a .
2. Place the **Support Rod(G)** to a suitable position as Fig.b .
3. Fasten the **Support Rod(G)** with screws as Fig.c .




8

Install **Top Pivot Sleeve(J)** and **Bottom Pivot Sleeve(K)**.

NOTE


- 1.Insert the **Top Pivot Sleeve(J)** to the **Glass Door(E)** as Fig.a and Fig.b .
- 2.After putting a little silicone on the **Bottom Pivot Sleeve(K)**, install it on the **Glass Door(E)** as Fig.c and Fig.d .



9 Install **Bottom Anti-Water Strip(F)**

NOTE



1. Apply a little silicone to the **Bottom Anti-Water Strip(F)** and insert it into the **Bottom Pivot Sleeve(K)** as Fig.a and Fig.b .
2. Cut off the **Bottom Anti-Water strip(F)** and align it with the **Glass Door(E)** as Fig.c、 Fig.d and Fig.e .



10 Install Glass Door(E)

NOTE

1. Install the **Glass Door(E)** on the **Bottom Bracket(D)** as Fig.a .
2. Secure the **Glass Door(E)** with the **Top Bracket(C)** as Fig.b .




11 Install **Handle(H)** and Wall Jamb Cover(I)

NOTE

1. Install the **Wall Jamb Cover(I)** on the **Wall Jamb(A)** as Fig.a .
2. Install **Handle(H)** as Fig.b .

Determine left or right according to the installation direction





12 SEALING

NOTE The surfaces need to be clean and free of debris before applying silicone.

NOTE Apply a good quality silicone sealant along the **Wall Jamb(A)** and Bottom **Stationary Glass(B)**.



Allow 24 hours for the silicone to cure before using the shower.



! Apply Silicone Sealant, (not supplied).