



CRAZY ELF vanity table

**T68S-W, T68S-B, T68S-W-L, T68S-B-L,
T68S-W-LS, T68S-B-LS**

INSTALLATION MANUAL



**T68 is type name, S is small size, W is white,
B is black, L is light, S is socket.**



There are two T68s, one with a revolving cabinet door on the left table and the other with a small drawer, the rest are exactly the same. This manual is for the revolving cabinet door model. If it is a small drawer model, simply replace the revolving cabinet door with the small drawer. The structure of the small drawer is as shown in Figure A, and the structure of the revolving cabinet door is as shown in Figure B




Figure A





Figure B

Before installation, please find a marker pen with erasable marks, distinguish each accessory based on the shape of the board and the position of the holes, and then write the corresponding numbers on the board.





1 -x1



2 -x1




3 -x1



4 -x1



5 -x1




6 -x1



7 -x1



8 -x3



9 -x1




10 -x1



11 -x1



12 -x2



13 -x1



14-x1




15-x2



16-x2




17-x1



for build-in
socket

or



18-x1

for not build-in
socket



for build-in
socket

or




for not build
-in socket

19-x1



20-x1



21-x1



22-x2



23-x2




24-x1



25-x8



26-x1



27-x1




28-x1



29-x3



30-x3



31-x3



32-x1

hardware



A	screw	x44
---	-------	-----



B	metal LOCK	x44
---	------------	-----



C	SCREW	x12
---	-------	-----



D	GUIDE RAIL	x2
---	------------	----



E	HANDLE SCREW	x5
---	--------------	----



F	L PLATE	x2
---	---------	----



G	screw	x9
---	-------	----




H	SOCKET	x1
---	--------	----

ONLY FOR 918S-LS



L	SCREW	x5
---	-------	----



J	SCREW	x47
---	-------	-----



K	PLASTIC LOCKS	x47
---	---------------	-----



I	HAIR DRYER STAND	x1
---	------------------	----


ONLY FOR 918S-LS



M	PIVOT PIN	x2
---	-----------	----


1. Screw installation method

When the screw is installed, please keep it in line with the board, and do not tighten it too tightly




2. Check the Nut direction



This direction of the marked nut is consistent with the direction in which the screw is inserted



3. Installation on the board with fixing screws





3. Rotate slowly until it stops





Step 01


pick up (26)x1, (27)x1, (28)x1, (25)x2 and (29)x3, (30)x3, (31)x3, (25)x6




Step 02



Step 03




Step 04




Three drawers are installed in the same way

Step 05

pick up ②x1, ③x1, ①x1, ⑤x1, ⑥x1, ④x1




Step 06




Step 07


pick up ⑦x1, ⑧x3, ②① x1, ⑨x1



Step 08




Step 09




Step 10

pich up ⑩ x1, ⑫ x2, ⑬ x1




Step 11


pick up ⑭ x1, ⑰ x1, ⑮ x2, ⑯ x2, ⑱ x1, ⑲ x1




Step 12




Step 13




Step 14



Step 15








Step 16




Step 18

For vanity table with light





If your vanity table include a LED mirror light, please test the light in this step. Touch the switch button on the mirror to turn on the mirror light, click the switch button to change the color of the light, and long press the switch button to adjust the brightness. If the switch button is not sensitive, you can check whether the touch switch is tightly attached to the mirror back as shown in the diagram. If it is not tightly attached, please use your fingers to press the touch switch to the designated position and check if the connecting wire is OK.

Step 17





Step 20








Step 19





Only for vanity table with hair dryer bracket and built-in socket

Step 21




Step 21




Fit the track section D1 of the mirror to the track section D2 on board 15, Maintaining the fit between D1 and D2, and then gently push the mirror to the left. There will be obvious resistance when pushing the mirror, which is normal. This resistance needs to be overcome till gradually close the mirror completely, but be careful not to apply too much force, as excessive force can cause the buffer stop at the left end of the track to deform, the buffer rubber is also easily to fall off. But it doesn't matter, just restore the buffer to its original state and reinstall the buffer rubber, it's OK.

Step 22




Please note that when placing the drawer in, the drawer positioning pin will block the drawer. Therefore, please follow the diagram to first insert the inner edge of the drawer using a concave method, and then push the drawer flat.



Only for vanity table with hair dryer bracket and built-in socket

Step 23



Step 24

