













CROSLEY

FURNITURE











Medium Storage Console CF1147



PART LIST


<div data-bbox="118 136 169 188">A</div> 	<div data-bbox="399 136 450 188">B</div> 	<div data-bbox="679 136 730 188">C</div> 	<div data-bbox="960 136 1011 188">D</div> 	<div data-bbox="1241 136 1292 188">E</div> 
<div data-bbox="140 412 341 456">Left Frame</div> <div data-bbox="199 483 288 528">1 PC</div>	<div data-bbox="416 412 643 456">Right Frame</div> <div data-bbox="486 483 576 528">1 PC</div>	<div data-bbox="767 412 847 456">Top</div> <div data-bbox="764 483 853 528">1 PC</div>	<div data-bbox="1038 412 1139 456">Shelf</div> <div data-bbox="1045 483 1134 528">1 PC</div>	<div data-bbox="1300 412 1437 456">Bottom</div> <div data-bbox="1326 483 1422 528">1 PC</div>
<div data-bbox="118 539 169 591">F</div> 	<div data-bbox="399 539 450 591">G</div> 	<div data-bbox="679 539 730 591">H</div> 	<div data-bbox="960 539 1011 591">I</div> 	<div data-bbox="1241 539 1292 591">J</div> 
<div data-bbox="124 815 373 860">Back Top Rail</div> <div data-bbox="199 927 288 972">1 PC</div>	<div data-bbox="416 815 643 904">Back Middle Rail</div> <div data-bbox="486 927 576 972">1 PC</div>	<div data-bbox="699 815 932 904">Back Bottom Rail</div> <div data-bbox="764 927 853 972">1 PC</div>	<div data-bbox="1002 815 1182 860">Front Rail</div> <div data-bbox="1045 927 1134 972">1 PC</div>	<div data-bbox="1241 815 1506 860">Partition Panel</div> <div data-bbox="1326 927 1422 972">1 PC</div>
<div data-bbox="118 983 169 1034">K</div> 				
<div data-bbox="209 1258 284 1303">Leg</div> <div data-bbox="180 1330 304 1375">4 PCS</div>				

HARDWARE LIST

<div>#1</div>  <div>Ø8mm*1-1/8"</div>	<div>#2</div>  <div>Ø1/4"*1-3/4"</div>	<div>#3</div> 	<div>#4</div>  <div>Ø1/4"*1-1/4"</div>	<div>#5</div>  <div>Ø1/4"*5/8"</div>
<div>Wood Dowel</div> <div>30 PCS (Extra 1)</div>	<div>Long Bolt</div> <div>8 PCS (Extra 1)</div>	<div>Crescent Washer</div> <div>8 PCS (Extra 1)</div>	<div>Middle Bolt</div> <div>9 PCS (Extra 1)</div>	<div>Short Bolt</div> <div>24 PCS (Extra 1)</div>
<div>#6</div> 	<div>#7</div> 	<div>#8</div> 	<div>#9</div>  <div>4mm</div>	<div>#10</div> 
<div>Metal Plate</div> <div>4 PCS</div>	<div>Cam Bolt</div> <div>10 PCS (Extra 1)</div>	<div>Cam Lock</div> <div>10 PCS (Extra 1)</div>	<div>Allen Wrench</div> <div>1 PC</div>	<div>Safety Strap Kit</div> <div>1 SET</div>

ADDITIONAL TOOLS (Not Provided)

Note: It is not recommended to use power tools during assembly.






Phillips Head Screwdriver

Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.

Step 1. Attach cam bolts (part #7) to left frame (part A), right frame (part B) and partition panel (part J).



Note: Do not overtighten cam bolts. Stop tightening once threads on cam bolt are no longer visible.





#7  x 10


Step 2. Attach top (part C) to partition panel (part J) using wood dowels (part #1), cam locks (part #8) and phillips head screwdriver.




Note: Cam locks must rotate a full 180°. See pictured insert.




- #1  x 2
- #8  x 2




Step 3. Attach shelf (part D) to partition panel (part J) using wood dowels (part #1), middle bolts (part #4) and allen wrench (part #9).



- #1  x 2
- #4  x 2
- #9  x 1



Step 4. Attach back top rail (part F) and back middle rail (part G) to assembled unit (parts C, D & J) using wood dowels (part #1), middle bolts (part #4) and allen wrench (part #9).





- | | | |
|----|--|-----|
| #1 |  | x 2 |
| #4 |  | x 2 |
| #9 |  | x 1 |

Step 5. Attach front rail (part I) to partition panel (part J) using wood dowel (part #1), cam lock (part #8) and phillips head screwdriver.



Note: Cam locks must rotate a full 180°. See pictured insert.



- | | | |
|----|---|-----|
| #1 |  | x 1 |
| #8 |  | x 1 |

Step 6. Attach left frame (part A) to assembled unit (parts D, F, G & I) using cam locks (part #8), wood dowels (part #1), long bolts (part #2), crescent washers (part #3), allen wrench (part #9) and phillips head screwdriver. Attach back bottom rail (part H) to left frame (part A) using long bolt (part #2), crescent washer (part #3), wood dowels (part #1) and allen wrench (part #9).



Note: Cam locks must rotate a full 180°. See pictured insert.



#1		x 8
#2		x 4
#3		x 4
#8		x 3
#9		x 1


Step 7. Attach right frame (part B) to the assembled unit (parts C, D, F, G & H) using cam locks (part #8), wood dowels (part #1), long bolts (part #2), crescent washers (part #3), allen wrench (part #9) and phillips head screwdriver.

Note: Cam locks must rotate a full 180°. See pictured insert.




#1		x 9
#2		x 4
#3		x 4
#8		x 4
#9		x 1


Step 8. Attach bottom (part E) to assembled unit parts (A, B & H) using wood dowels (part #1), middle bolts (part #4) and allen wrench (part #9).



Step 9. Attach metal plate (part #6) to leg (part K) using short bolts (part #5) and allen wrench (part #9).




Step 10. Attach assembled legs (part K) to bottom (part E) using short bolts (part #5) and allen wrench (part #9).









Step 11. Carefully turn unit upright.

Note: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. if relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.

Important: Safety strap kit (part #10) must be installed to prevent tipping, damage and/or injury.




#10	A	B	C	D	E
					
Safety Strap Kit 1 SET	Wall Anchor 1 PC	Bracket 2 PCS	Short Screw 1 PC	Long Screw 1 PC	Safety Wall Strap 1 PC

SAFETY WALL STRAP INSTALLATION

Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1. Insert short screw (C) and safety wall strap (E) through bracket (B) and attach to back top rail (part F) using philips head screwdriver.
2. Drill a 11/32" hole where you want to secure the unit. The drill hole will be at the same height as the hole in back top rail (part F) where bracket (B) is attached. Tap wall anchor (A) into the hole.
3. Insert long screw (D) and safety wall strap (E) through bracket (B) into wall anchor (A) using phillips head screwdriver.

Note: This item is not intended for clothing storage use.



⚠ WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!