

TOOLS REQUIRED









ASSEMBLY RATING



The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

CHECK	
CHECK BEFORE STARTING	
BEFORE STARTING	Check out our Quick Tips!
CHECK BEFORE STARTING Are you missing anything? Double-check all parts, hardware and accessories listed are all acccounted for.	Check out our Quick Tips! We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
BEFORE STARTING Are you missing anything? Double-check all parts, hardware and	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

SOFA



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS

1

2







SEAT FRAME 1 pc.


1 pc.


1 pc.

4

5

6








BACKREST 1 pc.

SEAT CUSHION

2 pcs

LEG 2 pcs

7



8



BIG SQUARE PILLOW

10

KIDNEY PILLOW 1 pc.

2 pcs

SMALL SQUARE PILLOW

9

SUPPORT LEG

2 pcs

2 pcs

HARDWARE


A В THREAD BOLT **FLAT WASHER LOCK WASHER** Ø5/16 x 22mm Ø5/16 x 31/4" Ø5/16 2 pcs 12 pcs 12 pcs F Ε D **BOLT SCREWS** ALLEN KEY M5 Ø5/16 Ø5/16 x 23/4" #4 x 70mm 1 pc. 4 pcs 10 pcs Н G **WRENCH HEX NUT**


12mm


1 pc.

Ø5/16 x 1/2"

2 pcs









5


Place the chair on its back on a clean and soft surface to reach the thread bolt (#C). Secure the backrest (#4) to the seat frame (#1) by using the Wrench (#H) with hardware #A, #B and #G.



6

Screw the support legs (#10) to the bottom of seat frame (#1).





and not for commercial use