TOOLS REQUIRED








Wrench (Included)



Phillips Screwdriver (Not Included)



2 - People Recommended


ASSEMBLY RATING



EASY — DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION #23-03-31



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



- · Please keep instructions for future reference.
- · Check the quantity and irregularity of parts and hardware before you start.



PARTS





Headboard Panel





HB Support





Support Leg (Long)

#2)2pcs



HB Leg (L&R)





Drawers



Support Leg(Short)

#31pc



Footboard





Bed Slat (13pcs)



Conceal Panel

#4)2pcs



Side Rail





Slat Center Support

HARDWARE





Bolt Ø5/16" x 2"



 $\leftarrow mmm$

Screw #4 x 30mm #B**)** 10pcs



Lock Washer Ø5/16"





Threaded Pins Ø5/16" x 3-1/2"





Flat Washer Ø5/16"





Hex Nut Ø5/16"




Allen Wrench 4mm





Half Moon washer Ø5/16"




Exploded view

Allen Wrench

4mm

Flat Washer Ø1/4"



packed in 4 caces

packed iii 4 caces							
Carton	Disignation		Part	Hardware			
	Headboard Panel	#1			#A 10pcs #B 10pcs		
	HB Support	#5	4		#C 10pcs		
	HB Leg (L&R)	#2			#D 1pc		
	Footboard	#3					
	Bed Slat	#7					
	Support Leg (Long)	#9	←				
	Slat Center Support	#8	· · · · · · · · · · · · · · · · · · ·		#E 15pcs #F 8pcs #G 8pcs #H 8pcs		
	Side Rail	#4			#I 1pc #J 8pcs #K 12pcs #L 12pcs #M 12pcs #N 1pc		
	Conceal Panel	#11					
	Support Leg (Short)	#10	←				
	Drawers	#6					

Part #1 ×1pc

Part #2 x2pcs
Part #5 x1pc


Hardware #A x10pcs

Hardware (#B) x10pcs

Hardware (#C) x10pcs

I. Align the L/R HB Leg (#2) to the Headboard Panel (#1) and secure using Bolts (#A) with Washers (# B,C).

II. Attach the HB Support (#5) to the HB Legs (#2) by using Bolt (#A) with washers (#B,#C).



2

Part #3 x1pc Part #4 x2pcs


Part #4) x2pcs Hardware #F) x8pcs Hardware #G) x8pcs


Hardware#H x8pcs


I. Attach the threaded pins (#F) to the Headboard leg (#2) and Footboard (#3).

II. Align the Side Rail (#4) onto the Headboard(#1) and Footboard (#3).


III. Secure by inserting the Half Moon Washer (#H) with the Hex Nut (#G). Use wrench (#I) to tighten the Hex Nut (#G).









5
Hardware#k x4pcs
Hardware#L x4pcs
Hardware#M x4pcs



Part #8x1pc Part #9x4pcs


Attach the Long Support leg (#9) to the Slat Center Support (#8). Use levelers to adjust height of the support leg.





Part #11 x2pcs
Hardware #J x8pcs

Attach the conceal panel (#11) to the slats by using screw(#E).



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.


Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

TOOLS REQUIRED



Phillips Screwdriver (Not Included)



2 - People Recommended

ASSEMBLY RATING



EASY — DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



Are you missing anything?	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed are all acccounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

NIGHTSTAND



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS






Nightstand

HARDWARE





Tipping Restrain



✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

secured.

✓ Lift, don't drag!


To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

Wall Mounting and Fixing



EXPANSION WALL ANCHOR

Our provided expansion wall anchors are only suitable for masonry walls, such as drywall, plaster or concrete, and are best for holding lightweight items or for anti-tip prevention. If you are unsure of the correct wall anchor to use with the product, please request professional guidance. Liability for product damage or failure due to using the incorrect anchors will fall on the installer.





CHECK BEFORE PROCEEDING

Prior to drilling or hammering, please check for wires or pipes. We recommend using a stud finder to locate a stud, which will offer more appropriate resistance and hold more weight.

QUICK TIPS


1.If unsure of the proper size, always choose a larger screw and wall anchor.






2. Match the drill bit to the wall anchor and hole size.

3. Only drill horizontally. Do not force the drill or enlarge the hole for the wall anchor.






4. Take extra care when drilling into high walls or ceramic tiles. Wall anchors should be a tight fit for the hole. Never use wall anchors in ceilings.





We recommend a yearly check to see if the wall anchor or screw has loosened. If so, please remove the existing wall anchor and screw, and use a new anchor.



TOOLS REQUIRED





2 - Persons Recommended

ASSEMBLY RATING



EASY — DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION # 23-03-31



Are you missing anything? Double-check all parts, hardware and accessories listed are all acccounted for.	Check out our Quick Tips! We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

DRESSER &MIRROR



- · Please keep instructions for future reference.
- · Check the quantity and irregularity of parts and hardware before you start.



PARTS

















Dresser

Support Leg

Mirror supports

Mirror

HARDWARE









Bolt Ø1/4" x 1-1/2"











#D) 1pc

Allen Wrench 4mm




Tipping Restrain

packed in 2 caces

Carton	arton Disignation		Part	Hardware	
	Dresser	#1		#E 1Set	
CM7413D	Support Leg	#2			
	Mirror supports	#3			
CM7413M	Mirror	#4		#A 6pcs #B 6pcs #C 6pcs #D 1pc	


Exploded view



1

Attach the Support Leg (#2) to the Dresser (#1).

Part #1 x1pc Part #2 x1pc



2


Part **#3** x 2pcs

Part #4 x1pc


Hardware(#A) x6pcs

Hardware#B x6pcs

Lift the mirror supports (#3). Align the Mirror (#4) to the supports (#3) and secure by using Bolt (#A) with washers (#B,C).



3 Hardware**#**E)×1pc



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!


To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

Wall Mounting and Fixing



EXPANSION WALL ANCHOR

Our provided expansion wall anchors are only suitable for masonry walls, such as drywall, plaster or concrete, and are best for holding lightweight items or for anti-tip prevention. If you are unsure of the correct wall anchor to use with the product, please request professional guidance. Liability for product damage or failure due to using the incorrect anchors will fall on the installer.





CHECK BEFORE PROCEEDING

Prior to drilling or hammering, please check for wires or pipes. We recommend using a stud finder to locate a stud, which will offer more appropriate resistance and hold more weight.

QUICK TIPS


1.If unsure of the proper size, always choose a larger screw and wall anchor.






2. Match the drill bit to the wall anchor and hole size.

3. Only drill horizontally. Do not force the drill or enlarge the hole for the wall anchor.





4. Take extra care when drilling into high walls or ceramic tiles. Wall anchors should be a tight fit for the hole. Never use wall anchors in ceilings.





We recommend a yearly check to see if the wall anchor or screw has loosened. If so, please remove the existing wall anchor and screw, and use a new anchor.