



RPC52FP36V2

Assembly Instructions




General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. A Phillips head screwdriver is required for the assembly of this product .



- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




VI HOW THE KNOCK DOWN (KD) ASSEMBLY SYSTEM WORKS


- 1.Screw the Cam Bolt into the pre-drilled hole on the panel. Make sure Cam Bolt goes into the pre-drilled hole on the end of panel for Cam Lock.
- 2.Insert the Cam Lock into the pre-drilled large hole on the panel. Make sure the arrow on the face of Cam Lock points towards Cam Bolt.
- 3.Take a Phillips screwdriver and rotate the Cam Lock clockwise to lock the Cam Bolt.
- 4.Use the sticker to conceal the Cam.


























- VII. Power tools should not be used to assemble this product .






Parts List




Hardware List

A		Ø8x30mm	Wood dowel	26 pcs
B		Ø6x35mm	Cam bolt	26 pcs
C		Ø15x11mm	Cam lock	26 pcs
D			Sticker	26 pcs
E		Ø4x25mm	Screw	16 pcs
F		Ø8x20mm	Wood dowel	8 pcs
G		Ø3.5x14mm	Screw	20 pcs
H			Glue	1 pc
I		Ø6x13mm	Bolt	6 pcs
J			Plastic wedge	12 pcs
K		Ø3x17mm	Flat-head screw	12 pcs
L		M 4	Hex key	1 pc
M		250mm	Plastic tracking	2 pcs
N			Hanger	2 pcs
O			Door stopper	4 pcs
P		Ø3.5x20mm	Screw	8 pcs
Q		Ø4x44mm	Screw	4 pcs
R			Knob	2 pcs
S		Ø4x16mm	Handle bolt	2 pcs
T		90x50mm	L shape bracket	2 pcs
U		Ø4x12mm	Screw	4 pcs
V		35x35mm	L shape bracket	4 pcs
W		Tipping Restraint Hardware		2 sets


Hardware List

X		RV36V80L-MT1	Fireplace Insert	1 pc
Y			Connector	3 pcs
Z			Plate	4 pcs




Philips head screwdriver required for assembly
(not included)


Step 1




Step 2




Step 3




Step 4





Step 5





Step 6




Step 7





Step 8




Step 9




Step 10




Step 11




Step 12




Step 13




Step 14




Step 15




Step 16



Step 17






Step 18






Step 19

Tilt a door to let the hanger (N) catch the front end of plastic tracking (M) as shown.




Step 20


Push doors inside, then insert door stopper




Step 21



Step 22






Step 23



Step 24

WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.



Use stickers(D) to conceal cam locks(C)

Final Assembly