


ASSEMBLY INSTRUCTIONS



CAUTION

◆ Inspect the wire insulation for any cuts, abrasions, or exposed copper that may have residue during shipping. If there is a defect in the wire, do not attempt installation.

◆ Before starting installation of this fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.

TOOLS REQUIRED



Ladder



Safety Goggles



Electrical Tape



Phillips Screwdriver



Flathead Screwdriver




Wire Cutter




Wire Stripper


HARDWARE INCLUDED




Fixture




Mounting Unit




Canopy




Glass shade 6pcs




wrench



Tube L600mm




Mounting Screws




Wire Nuts


*PARTS SHOWN MAY DIFFER SLIGHTLY PER LIGHT FIXTURE

EXPLODED PARTS






Step1:Open the nuts by the wrench, then put the tube into the fixture and locked it with the nust. If the wire is too long then making it hard to put in the tube, you can open the bottom cap, to fix the wire then install the tube again.




Step2: Put the wire into the L600 tube, then put the tube into the fixture. Meanwhile, install the L600 tube into the canopy.




Mounting Screws

Step 3 Put the mounting unit into the junction box, fixed it with the mounting screws.




STEP 4


Make the electrical connection from the junction box to the fixture.
Connect the ground wire to the mounting unit using the preinstalled green ground screws.
Then, connect the positive, negative and ground wires with the supplied wire units, Secure with electrical tape.



Step 5 Install the fixture to the junction with the screws.



Step 6 Install the light bulb, then put the glass into the socket as



Step 7 Finish the installation.